# **ASSEMBLY**

## **INSTRUCTIONS**

## ITEM NO: B8100/B8130 - K - HB/FB/KQ - RAIL KING HEADBOARD/FOOTBOARD/SIDE RAIL

#### (BOX 1) BOX OF HEADBOARD

#### ITEM DRAWING DESCRIPTION QTY HEADBOARD PANEL 1 LEFT В HEADBOARD LEG RIGHT 1 HEADBOARD LEG HB BOTTOM RAIL 1 D HB WOOD BLOCK 2 E

#### (BOX 2) BOX OF FOOTBOARD

ITEM	DRAWING	DESCRIPTION	QTY
F		FOOTBOARD	1
G		WOODEN SLAT	4
Н	1	WOODEN SUPPORT	8

#### (BOX 3) BOX OF SIDE RAIL


ITEM	DRAWING	DESCRIPTION	QTY
I		SIDE RAIL	2

#### (BOX 1) HEADBOARD HARDWARE LIST

ITEM	DRAWING	DESCRIPTION	QTY
1		ALLEN WRENCH (M4(BALL SHAPE)110mm)	1
2		ALLEN WRENCH (M5)	1
3	<b>9</b>	CONNECTION BOLT (M8 x 20mm) W/WASHER & SPRING WASHER	8
4	9 <b>0</b> 000	CONNECTION BOLT (M6 x 40mm) W/WASHER & SPRING WASHER	8
5	97 <b>9</b> 000	CONNECTION BOLT (M6 x 50mm) BIG W/WASHER & BIG SPRING WASHER	2
6	97 <b>9</b> 000	CONNECTION BOLT (M6 x 60mm) SMALL W/WASHER & SMALL SPRING WASHER	2
7		WOOD DOWEL (M8 x 30mm)	8
8	(Amma	FLAT HEAD SCREW (#8 x 1 1/8")	8
9		Assembly Tool Not Included	1



 $\frac{COMPLETED\ KING\ BED}{ASSEMBLY}$ 




#### THE HARDWARE IS LOCATED IN THE PACKING ITEMS

NOTE : MUST TIGHTEN SCREWS PERIODICALLY. WITH USE SCREW MAY BECOME LOOSE. CHECK TIGHNESS OF ALL SCREW EVERY 6-8 WEEKS.

### **CLEANING INSTRUCTION**

## ASSEMBLY INSTRUCTIONS

ITEM NO: B8100/B8130 - K - HB / FB / KQ - RAIL KING HEADBOARD / FOOTBOARD / SIDE RAIL



#### THE HARDWARE IS LOCATED IN THE PACKING ITEMS

NOTE: MUST TIGHTEN SCREWS PERIODICALLY. WITH USE SCREW MAY BECOME LOOSE. CHECK TIGHNESS OF ALL SCREW EVERY 6-8 WEEKS.

## **CLEANING INSTRUCTION**