


ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

603506 Glider Recliner

REVISION 0: 10/15/2020

ITEM: 603506





ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

5 MINUTES

PARTS IDENTIFICATION

A BACK 1PC

B BASE 1PC


C LEFT EAR 1PC

ITEM: 603506




ASSEMBLY INSTRUCTIONS


STEP 1



STEP 2



STEP 3



STEP 4 COMPLETE




PAGE 3 OF 3




COASTERFURNITURE.COM

ITEM: **603506**







Note: Dimension tolerance ±5%