

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

222524 *Mirror*

REVISION 0: 08/20/2025

ITEM: 222524

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediatelly.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

10 MINUTES

PART IDENTIFICATION

A DRESSER *FROM BOX ITEM 222523*



1PC

B MIRROR

1PC

C MIRROR SUPPORT (PACKED WITH MIRROR)




2PCS

HARDWARE IDENTIFICATION


1 BOLT (5/16" x 35mm - BLK) 8PCS
2 LOCK WASHER (1.6 x 14mm - BLK) 8PCS

3 FLAT WASHER (2 x 19mm - BLK) 8PCS

4 ALLEN WRENCH (M5 x 65mm - BLK)







Note: Dimension tolerance ±5%