


MODEL #

FM-BK903BK-TT

Questions?

GIVE US A CALL: 1-888-980-5122 MON-FRI 8:30AM-5:30PM (PT)


TOOLS REQUIRED



Allen Wrench



2- People



EASY ------ DIFICULT

The Assembly Rating is a 5-point system showing the level of effort needed to assemble a speccific product.








Thank you for your purchase!

We hope you enjoy this new addition to your home for many years to come.

Our commitment to providing quality products does not simply end when you purchase our product. We fully stand behind our products from start to finish. Our customer service department is available Monday – Friday 8:30 AM – 5:30 PM Pacific Time and can help with assembly questions as well as, if necessary, replacing damaged or missing parts. To help expedite our service, please have these assembly instructions readily available, along with your order receipt.



PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.






Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.







Suitable Location


Assembling near the area of the intended location is highly recommended.



Sufficient Space

Make sure you have enough space to move around during the assembly.









Avoid Scratches

carpeted area while assembling furniture to prevent to prevent scratches and damages.

Use cardboard, blankets or a

Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.

ASSEMBLY AND CARE ADVICE



FAILURE TO FOLLOW THE GUIDELINES BELOW MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.



Postion each part correctly and insert screws or bolts into their respective holes



Turn clockwise to tighten and only tighten when step is completed or when instructed to do so.



347

or power tools for assembly. Select steps, such as tightening screws and/or botls, may require hand tools to avoid causing damage during assembly.

Use the appropriate hand tools



Save the instructions and store any supplied tools for later maintenance. Affer two weeks, check and tighten amy loose hardware and repeat again every six months thereafter.


IT IS USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.

METAL TWIN OVER TWIN BUNK BED FM-BK903BK-TT

 Please keep instructions for future reference.

Check the quantity and irregularity of parts and hardware before you start.

PARTS



HARDWARE

∉A) x16



Bolts 1/4" x 60





Bolts 1/4" x 35

₩C) x27



Bolts 1/4" x 15

#D x8



Cover Ø42






Cover 20 x 20

#₽ x1





Allen wrech M4 x 59




Connect Wall 1/4" x 40


Exploded View







STEP 2 :







STEP 3 :






STEP 4 :







STEP 7:



This product is intended for RESIDENTIAL USE ONLY and not for commercial use.

Safety Warnings for Bunk Beds

1. Read and follow the information on the WARNING labels shown on the end structure of the upper bunk and on the carton.

2. Do not remove warning labels from the bed.

3. Keep these instructions for future use.

4. IMPORTANT: The proper sizes for the UPPER TWIN-SIZE mattress should be 74"-75" long and 37 $\frac{1}{2}$ "-38 $\frac{1}{2}$ " wide with no more than 6" thickness and for the LOWER TWIN-SIZE should be 74"-75" long and 37 $\frac{1}{2}$ "-38 $\frac{1}{2}$ " wide with mattress thickness at least 8" and does not exceed 11".

5. Surface of mattress must be at least 5 inches (127 mm) BELOW the upper edge of the guardrails.

6. The MAXIMUM weight capacity for the upper bunk is not to exceed 150 lbs.

7. Do not allow children under 6 years of age to use the upper bunk.

8. Periodically check and ensure that the guardrails, ladder, handle and other components are in their

proper position, free from damage, and that all connectors are tightened and secured.

9. DO NOT allow horseplay, rough playing, or jumping on the beds and do not allow playing or hiding

under the beds.

10. Always use the ladder for entering or leaving the upper bunk.

11. Do not use substitute parts. Contact the manufacturer or dealer for replacement parts.

12. Use of a nightlight may provide added safety precaution for a person using the upper bunk.

13. Always use the guardrails on both sides of the upper bunk.


14. If the bunk bed will be placed next to a wall, the guardrail that runs the full length of the bed should be

placed against the wall to prevent entrapment between the bed and the wall.

15. The use of water or sleep flotation mattresses is prohibited.

16. No more than one person is allowed on the upper bunk at all times.

17. Always use the recommended size mattresses or mattress supports, or both, to help prevent the likelihood of entrapment or falls.



Objects such as, but not limited to, hanger, hooks, belts, bag, rope strings, etc. should not be hanged or used on or around the bunk bed.

Replacement Parts:

Replacement parts may be obtained from your Furniture of America dealer.

Distributed by: Furniture of America 680 S. Lemon Avenue City of Industry, CA 91789