
## **PRODUCT DIMENSIONS**

## **RB900**



NOTE: MAKE SURE THE DISCHARGE END OF THE REMOTE BLOWER FACES AWAY FROM THE DIRECTION OF THE PREVAILING WINDS. INSTALL THE DISCHARGE END OF THE FAN FACING AN UNOCCUPIED SPACE

PAGE 7