


ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

REVISION 0 : 05/14/2008 REVISION 1 : 12/04/2012 REVISION 2 : 08/09/2017 REVISION 3 : 09/11/2018 REVISION 4 : 12/02/2019 200710 Elevation Platform Side Panel

PAGE 1 OF 3

COASTERFURNITURE.COM

ITEM:200710



ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

15 MINUTES

PARTS IDENTIFICATION

A HEADBOARD EXTENSION PANEL



2PCS

HARDWARE IDENTIFICATION

1 FLAT HEAD SCREW (M4 x 20mm - BLK)



16PCS


METAL PLATE 2 (3 x 25 x 150mm - BLK)



4PCS


NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.



ITEM:200710





NOTE: DIMENSION TOLERANCE ± 5%

COASTERFURNITURE.COM