








Assembly Instruction

Item No: U6023-13P1

KELLEN GLIDER RECLINER W/

Thank you for purchasing this quality product. Be sure to check all parts and materials carefully for small parts, which may have come loose during shipping. Identify and count all items and compare with the parts list shown below.


It is recommended to have two people during unpacking and assembly. Remove the backs and base of the furniture out from the box.

Parts List		
NO.	DESCRIPTION	SKETCH
A	SEAT	
B	BACKREST	
C	LEFT SIDE FACING (LSF) WING	
D	RIGHT SIDE FACING (RSF) WING	
E	POWER CABLE 29V	


WEIGHT CAPACITY (PER SEAT) : 350 LBS

Please follow the drawings below to assemble

STEP 1: Cut and remove the fasteners on the frame at the bottom of the seat (A).



STEP 2: Install the backrest (B) onto the bracket on the backrest (B) to the seat (A). Please make sure the bracket is properly aligned and secured into position.




Assembly Instruction


Item No: U6023-13P1

KELLEN GLIDER RECLINER W/

STEP 3: Install the wings by inserting metal bracket on the LSF wing (C) and RSF wing (D) into the metal bracket on the backrest (B). Please make sure the brackets are inserted all the way and secured into position.



STEP 4: Connect the Power Cord (E) to the power seat (A).



STEP 5: Open/close the footrest by pressing the power buttons.

