


ASSEMBLY INSTRUCTIONS ***COASTER FINE FURNITURE***



Fine Furniture for every stage of life

710757
End Table

ITEM: **710757**



ASSEMBLY INSTRUCTIONS


ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



Warning !!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishment.




ASSEMBLY TIME

30 MINUTES


PARTS IDENTIFICATION

A TOP PANEL




1 PC

B SIDE PANEL



2 PCS

C CROSSBAR







1 PC

NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

HARDWARE IDENTIFICATION

1	LARGE CAMBOLT (Ø7 x29mm)		6pcs
2	LARGE CAMBOLT (Ø15x12mm)		6pcs
3	WOOD DOWEL (Ø8 x 25mm)		1pc
4	CROSS SCREW (Ø6 x 25mm)		4pcs

NOTE:


Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM: **710757**




ASSEMBLY INSTRUCTIONS

STEP 1



STEP 2




ITEM: **710757**




ASSEMBLY INSTRUCTIONS

STEP 3



STEP 4




ITEM: **710757**




ASSEMBLY INSTRUCTIONS

STEP 5




STEP 6



ITEM: **710757**




ASSEMBLY INSTRUCTIONS
STEP 7




ITEM: **710757**



DIMENSION



ASSEMBLY INSTRUCTIONS ***COASTER FINE FURNITURE***



Fine Furniture for every stage of life

710758
Coffee Table

ITEM: **710758**



ASSEMBLY INSTRUCTIONS


ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



Warning !!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishment.




ASSEMBLY TIME

30 MINUTES


PARTS IDENTIFICATION

A TOP PANEL




1 PC

B SIDE PANEL



2 PCS

C CROSSBAR







1 PC

NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

HARDWARE IDENTIFICATION

1	LARGE CAMBOLT (Ø7 x29mm)		6pcs
2	LARGE CAMBOLT (Ø15x12mm)		6pcs
3	WOOD DOWEL (Ø8 x 25mm)		1pc
4	CROSS SCREW (Ø6 x 25mm)		8pcs

NOTE:


Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM: **710758**




ASSEMBLY INSTRUCTIONS

STEP 1



STEP 2




ITEM: **710758**




ASSEMBLY INSTRUCTIONS

STEP 3



STEP 4




ITEM: **710758**




ASSEMBLY INSTRUCTIONS

STEP 5




STEP 6



ITEM: **710758**




ASSEMBLY INSTRUCTIONS
STEP 7



ITEM: **710758**



DIMENSION



Note: Dimension tolerance $\pm 5\%$