


USER GUIDE

Parts



URDR424-IS61A		
Item	Description	Part Number
1	ANTI-TIP BRACKETS, BLACK	90-54215-00
2	BACK PANEL ASSY, 24"	90-54214-00
3	COMPRESSOR ASSY - FMSA4C (115V SERIAL)	90-54214-03
4	CONDENSER ASSY - 24"	90-54215-01
5	CONDENSER FAN ASSY, PX, STANDARD	90-54214-01
6	DRAIN PAN	90-54214-05
7	DRAWER ASSY, 24", INT., BOTTOM, BLK	90-54218-13
8	DRAWER ASSY, 24", INT., TOP, BLK	90-54218-14
9	DRIER FILTER	90-54218-07
10	EVAP COVER 24"	90-54215-02
11	EVAPORATOR, BLACK	90-54215-03
12	FAN, EVAPORATOR ASSEMBLY	90-54218-06
13	GASKET, DRAWER	90-54218-08
14	GRILLE ASY - ADJUSTABLE, 24" BLACK	90-54214-24
15	LEG LEVELERS	90-54158-00
16	LIGHT ASSY LED, VYV	90-54214-16
17	MAIN BOARD	90-54214-02
18	RGB LED ASSY. PX, SHORT	90-54214-15
19	SELCO THERMISTOR-BLACK	90-54214-14
20	SLIDE ASSEMBLY, URDR	90-54218-11
21	SWITCH, LIGHT	90-54218-10
22	THERMISTOR W/COVER-BLACK LOKR224	90-54205-09
23	USER INTERFACE, DRAWER, BLK	90-54218-12
24	WIRE HARNESS ASSY, STD *	90-54214-06
25	WOOD INTEGRATED KIT *	90-54214-26
26	CARBON FILTER ASSEMBLY-UL	90-54224-01

*NOT PICTURED

