

Assembly Instruction for DINING SIDE CHAIR DMI100SC


Caution: Please read instructions thoroughly before unpacking assembly parts. Sharp, exposed staple tips can cause injury, therefore, for your protection, please remove any exposed staples used in packing.

1. We recommend that you should assemble this product with the assistance of another person; this will make assembly easier, and will help to eliminate damage the product or injury to persons during assembly.
2. Be sure to check all packing materials carefully for small parts that may have come loose inside the carton during shipment.
3. Please do not over tighten screws or bolts.
4. Please put all parts on a non-abrasive floor before assembly, and follow the assembly steps to assemble your newly purchased product correctly and efficiently.


PART LIST			
NO.	PART DESC	CODE	Q'TY
A	DINING SIDE CHAIR - BLACK PU UPHOLSTERED BACK FRAME	PDMI100SCBFR	1
B	DINING SIDE CHAIR - FULL SEAT CUSHION	PDMI100SCSEA	1
C	DINING SIDE CHAIR - LEFT / RIGHT FRONT LEG	PDMI100SCLEG	2

HARDWARE LIST			
NO.	HARDWARE DESC	CODE	Q'TY
1	 BOLT Ø5/16"x80mm	PDMI100SCHW	4
2	 BOLT Ø5/16"x55mm		6
3	 LOCK WASHER Ø5/16"		10
4	 FLAT WASHER Ø5/16"		10
5	 ALLEN KEY M5		1


STEP 1



STEP 2



COMPLETED



MADE IN VIETNAM