



















A, B, C, D, E : mm (inches / pulgadas / po)
F, G : kg (lbs / libras / lb)

MODELS	A		B		C		D		E		F		F-G		Power consumption
MODELLOS	A		B		C		D		E		F		F-G		Consumo de potencia
MODÈLES	A		B		C		D		E		F		F-G		Consommation électrique
OLED83C2AUA OLED83C2PUA	1,851 (72.8)	1 851 (72.8)	1,092 (42.9)	1 092 (42.9)	279 (10.9)	279 (10.9)	1,062 (41.8)	1 062 (41.8)	55.3 (2.1)	55.3 (2.1)	41.6 (91.7)	41,6 (91,7)	32.3 (71.2)	32,3 (71,2)	802 W
Power requirement / Alimentación requerida / Alimentation									AC 120 V~ 50/60 Hz						



A	B	C x D (mm)	E
LSW440B	OLED83C2*	400 (15.7) x 400 (15.7) 400 (15,7) x 400 (15,7)	M6

C, D : mm (inches / pulgadas / po)



A	B	C x D (mm)
WB21EB	OLED83C2*	180 (7.0) x 55 (2.1) 180 (7,0) x 55 (2,1)



ENGLISH Read **Safety and Reference**.

ESPAÑOL Leer **Seguridad y Consultas**.

FRANÇAIS Lisez **Sécurité et références**.

ENGLISH

Easy Setup Guide

Please read this manual carefully before operating your set and retain it for future reference.

ESPAÑOL

Guía Rápida de Configuración

Lea atentamente este manual antes de poner en marcha el equipo y consérvelo para futuras consultas.

FRANÇAIS

Guide de configuration rapide

Avant d'utiliser l'appareil, veuillez lire attentivement ce manuel et le conserver pour pouvoir vous y reporter ultérieurement.

⊕ : Depending upon model / Según el modelo / Selon le modèle