RADIANT COOKTOP

		LCE3010SB	LCE3610SB
түр	E	ELECTRIC	ELECTRIC
	Size	30"	36"
	Cooking Surface	Radiant Glass Surface	Radiant Glass Surface
	Number of Elements	5	5
FEA	TURES		
	Controls Type / Location	SmoothTouch [™] Glass Controls / Front Center	SmoothTouch [™] Glass Controls / Front Center
	Hot Surface Indicator		
	Child Lock	•	
	Auto Shutoff		
	Under Counter Oven Capable		
	Warm Function		•
	Accessories	N/A	N/A
cor	NFIGURATION		
	Left Front	6" / 1200W	6" / 1200W
	Left Rear	8" / 1900W	8" / 5" 1900 / 950W (Dual)
	Center	7" / 1500W	12" / 9" / 6" 3000 / 2200 / 1100W (Triple)
	Right Front	9" / 6" 3000 / 1400W (Dual)	9" / 6" 3000 / 1400W (Dual)
	Right Rear	6" / 100W (Warm)	6" / 100W (Warm)
MA'	TERIALS / FINISHES		
	Available Colors	Smooth Black	Smooth Black
	Elements	Grey Patterned on Black Ceramic Glass	Grey Patterned on Black Ceramic Glass
	Surface / Frame Trim	Ceramic Glass / No Trim	Ceramic Glass / No Trim
DIN	IENSIONS		
	Product (W x H x D)	30 ²⁷ / ₃₂ " × 4" × 21 ¹ / ₂ "	36 ¹¹ /16" x 4" x 22"
	Cutout (W x D)	29 ³ /8" × 20 ¹ /4"	34 ⁹ /16" × 20 ³ /8"
	Net Weight	34 lbs	43 lbs
PO\	VER SOURCE		
	Electrical Requirements	240V / 208V, 60Hz AC	240V / 208V, 60Hz AC
	Max. Amp Load @ 240V	40 Amp	50 Amp
	Power Cable Location	Right Rear	Right Rear
	Total Connection Load	7.7kW @ 240V, 5.8kW @ 208V	10.5kW @ 240V, 7.9kW @ 208V



INCHES	А	в	С	D	E	F (MIN)	G (MIN)	н	I (MAX)	J (MAX)	к	L
30-Inch Models	30 27/32	21 ¹ /2	3 3/4	28 ¹³ /16	19 ⁵ /8	29 ³ /8	20 ¹ /4	13/16	13	5 ²³ /32	2 ¹ /2	24
36-Inch Models	36 ¹¹ /16	21 ¹⁵ /16	3 3/4	33 27/32	19 ^{25/32}	34 ⁹ /16	20 ³ /8	13/16	13	5 23/32	2 ¹ /2	24
All electric constrons run off a single phase three-wire or four-wire cable 240 / 208 volt 60 hertz AC-only electrical supply around. Minimum distance between constron and overhead cabinetry is 30" Allow 2" space below the												

All electric cooktops run off a single phase, three-wire or four-wire cable, 240 / 208 volt, 60 hertz, AC-only electrical supply ground. Minimum distance between cooktop and overhead cabinetry is 30". Allow 2" space below th armored cable opening to clear the electric cable and allow space for installation of the junction box on the wall at the back of the cooktop.