ASSEMBLY Instructions

ITEM NO: B3050-7


MEDIA CHEST


BOX OF MEDIA CHEST

ITEM	DRAWING	DESCRIPTION	QTY
A		MEDIA CHEST	1
В	B	LEFT FRONT LEG (Packed inside drawer)	1
С		RIGHT FRONT LEG (Packed inside drawer)	1
D	(D)	LEFT BACK LEG (Packed inside drawer)	1
E	E	RIGHT BACK LEG (Packed inside drawer)	1
F		SUPPORT LEG	1
G		TIPPING RESTRAINT (Affix to wall behind dresser) *Located at the back panel	1

HARDWARE LIST

ITEM	DRAWING	DESCRIPTION	QTY
1		JCBC BOLT WITH SPRING WASHER AND FLAT WASHER (M6 x 40mm)	8
2		ALLEN KEY (M4)	1





NOTE: MUST TIGHTEN SCREWS PERIODICALLY. WITH USE SCREWS MAY BECOME LOOSE. CHECK TIGHNESS OF ALL SCREWS EVERY 6-8 WEEKS.