


B E R N H A R D T


I N T E R I O R S

EDEN SECTIONAL




ARMLESS CHAIR N2730

W 30 | D 40.50 | H 33 in.
SH 16.50 | SD 26 in.




CORNER CHAIR N2732

W 40.50 | D 40.50 | H 33 in.
SH 16.50 | SD 26 in.




LEFT ARM LOVESEAT N2742

W 64.50 | D 40.50 | H 33 in.
SH 16.50 | AH 27.50 | SD 26 in.



RIGHT ARM LOVESEAT N2741

W 64.50 | D 40.50 | H 33 in.
SH 16.50 | AH 27.50 | SD 26 in.



ARMLESS LOVESEAT N2740

W 60 | D 40.50 | H 33 in.
SH 16.50 | SD 26 in.