

WINNERS ONLY®

Assembly Instructions

PROD.NO.:DKT345024

Thank you for purchasing this quality product. Please read instructions thoroughly before unpacking assembly parts.

Caution: Sharp, exposed staple tips can cause injury. Therefore, for your protection, please remove any exposed staples used in packing.

Please keep all hardware parts out of the reach of children.








1. We recommend that you should assemble this product with the assistance of another person; this will make assembly easier and will help to prevent personal injury and to insure parts are not damaged during assembly process.

2. Before beginning, please check packing materials carefully for small parts that may have come loose inside the carton during shipping. Do not discard any packing material until all parts have been located. If any parts are missing, please contact your dealer for prompt replacement.

3. To prevent damage to your floor or carpet, please check the bottom of each piece of furniture for stain residues and rough surface and also check for staples or nail left after removing the packing materials. The manufacturer will not be held responsible if preventive steps are not taken prior to installation.


4. Please do not over tighten screws or bolts. During normal use everyday screws, bolts, nuts and wooden plugs may loosen up. They should be periodically inspected and re-tightened to prevent damage to the furniture and (or) personal property or cause injury. Always check to be sure all hardware on this list and below mentioned components are attached to the furniture properly and kept tightened.

5. Please lay all parts and hardware on a non-abrasive surface such as a carpet and follow the assembly.


NO.	SKETCH	PARTS LIST	Q' ty
A		Back Rest	1
B		Cushion Seat	1
C		Front Left Leg	1
D		Front Right Leg	1
E		Left Side Stretcher	1
F		Right Side Stretcher	1
G		Front Stretcher	1

NO.		HARDWARE LIST	Q' ty
1		JCBC Ø1/4"*38mm	2
2		JCBC Ø1/4"*70mm	4
3		Ø1/4"-13mm Spring washer	6
4		Ø1/4"-19mm*2mm(T) Flat washer	6
5		Nut Ø5/16"*13mm(W027)	4
6		Ø5/16"-13mm Spring washer	4
7		Ø5/16"-19mm*2mm(T) Flat washer	4
8		Screw Ø8*32mm	6
9		Allen Key (4mm)	1
10		Wrench (12.8mm)	1


TIP: Store the Allen key and Wrench in assembly in this product drawer or use masking or painter tap to affix it to the underside of the product. This will make it easier to find if you want to periodically tighten bolts or disassemble the product.



STEP 2



STEP 1 FIG.1



STEP 1 and 2: Attach the chair Back Rest (A) to the Cushion Seat (B) using provided hardware as shown on FIG.1/ FIG.2

WINNERS ONLY[®]

Assembly Instructions

PROD.NO.:DKT345024

STEP 3: Attach Front Legs (C) & (D) to the corner blocks of the Cushion Seat (B) using provided hardware as shown on FIG.3

STEP 4: Attach the Front Stretcher (G) and Side Stretchers (E,F) to the Front Leg (C,D) & the Back Rest (A) using provided hardware as shown on FIG.4.

STEP 3




FIG.3

STEP 4





FIG.4

STEP 5: Turn the chair to standing position. Check it's balance and tighten all screws and bolts to complete assembly.



Assembly is now completed.