

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life


708417 <u>End Table</u>

ITEM:**708417**



STEP 1


* PLEASE REMOVE THE WOOD STRIP BEFORE USE.



NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.


STEP 2 COMPLETE





ITEM:**708417**





Note: Dimension tolerance ±5%