

Escape Dining Chair 2618

Overall: 25.5" x 24.5" x 38"

Firm Seat

Back Depth: 5"

Back Width 22.5"

Arm Width: 3"

Bottom to Floor: 0.5"

On Casters

