


ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

181367
SERVING CART

REVISION 0 : 08/01/2022

PAGE 1 OF 8

COASTERFURNITURE.COM

ITEM:181367



ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME 45 MINUTES

PARTS IDENTIFICATION

A	GLASS		2PCS
B	TOP FRAME		1PC
C	BOTTOM FRAME		1PC
D	HANDLE		1PC
E	CROSSBAR		4PCS

ITEM:181367

ASSEMBLY INSTRUCTIONS

PARTS IDENTIFICATION



F


FRAME BRACKET



8PCS

G


WHEEL



2PCS

H

WHEEL WITH LOCK



2PCS









ITEM:181367



ASSEMBLY INSTRUCTIONS

Z

HARDWARE IDENTIFICATION

1	SHORT BOLT (3/16" x 9mm SR)		8PCS
2	MEDIUM BOLT (3/16" x 15mm SR)		8PCS
3	LONG BOLT (3/16" x 32mm SR)		2PCS
4	SUCTION CUP (ϕ 19 x 9mm)		8PCS
5	ROUND CAP (ϕ 18mm SR)		2PCS
6	CAP (10 x 20mm SR)		4PCS
7	WHEEL CAP (10 x 20mm BLK)		4PCS
8	ALLEN WRENCH (4mm)		1PC


ITEM:181367




ASSEMBLY INSTRUCTIONS

STEP 1


Do not tighten until each step is completed or instructed.




STEP 2




ITEM:181367
ASSEMBLY INSTRUCTIONS
STEP 3




STEP 4



ITEM:181367
ASSEMBLY INSTRUCTIONS
STEP 5



STEP 6
COMPLETE




ITEM:181367

ASSEMBLY INSTRUCTIONS



Product Size : 527 DIA X 787 H (MM)

Product Size : 20.75" X 31"



Note : Dimension tolerance $\pm 5\%$