




FRIGIDAIRE

Factory Parts Catalog

Product No.	FGEC3068UB	FGEC3068US
	949163355	949163356
Series	30" elec	30" elec
Color	black	stainless
Market	North America	North America
Wiring Diagram	A14025202	A14025202
Owner's Guide	A01704202	A01704202
Installation Instructions	A01705002	A01705002

Frigidaire

P.O. BOX 8020
CHARLOTTE, NC 28262


**This Publication Replaces
Publication # 5995704698**

Publication No.
5995705737
18/07/26
(EN/SERVICE/ECL)
377

30" ELECTRIC COOK-TOP

Model No.
FGEC3068U

CONTROL PANEL




CFGEC3068US

CONTROL PANEL

Model Index: **A** FGEC3068U (FGEC3068UB)
 B FGEC3068U (FGEC3068US)

POS. NO	PART NO.		DESCRIPTION
7	5304518265	A B	Insulation, control box
8	319224001	A B	Screw, switch mtg., M4 x 7
9	5304518266	A B	Bracket, grounding, control box
*	305452800	A B	Screw, ground
10	5304515131	A B	Spacer, silicone seal, switch shaft
11	5304518250	A B	Spacer, turbo boil, silicone seal, switch shaft
15	5304518267	A B	Control Box, plastic, 5 zone
16	305638977	A -	Maintop, assembly, black, w/5 bushings
16	305638978	- B	Maintop, assembly, black/stainless, w/5 bushings
35	5304515130	A B	Bushing, knob, sealing
36	5304518268	A -	Knob, control, black, single element
36	5304518252	- B	Knob, control, stainless, single element
36A	5304518269	A -	Knob, control, black, dual element
36A	5304518253	- B	Knob, control, stainless, dual element
36B	5304518270	A -	Knob, control, black, turbo boil
36B	5304518254	- B	Knob, control, stainless, turbo boil
54 #	305458905	A B	Switch, infinite, single control
54A#	318191001	A B	Switch, infinite, dual control
54B#	5304518255	A B	Switch, infinite, turbo boil

MAIN TOP/SURFACE UNITS



MAIN TOP/SURFACE UNITS

Model Index: **A** FGEC3068U (FGEC3068UB)
B FGEC3068U (FGEC3068US)

POS. NO	PART NO.		DESCRIPTION
3	387683500	A B	Support, burner box
4	387683300	A B	Bracket, surface element
*	5304462994	A B	Screw, 8-32 x 5/16
5	5304518258	A B	Bracket, support, Z style
6	387372900	A B	Spring, surface element
10	5304518263	A B	Box, support, inner, element
11 #	387812007	A B	Light Assembly, indicator, hot surface
13	330447900	A B	Screw, B4, 2 x 9, 5
14	5304518260	A B	Support, beam
*	305376101	A B	Screw, bracket, surface element
15 #	374063522	A B	Element, surface, 6", 1200W
15A#	374063622	A B	Element, surface, 7", 1800W
15B#	316530001	A B	Element, surface, 9", 3200W, turbo boil
15C#	318198952	A B	Element, surface, dual, 750/1800W
16	305638977	A -	Maintop, assembly, black, w/5 bushings
16	305638978	- B	Maintop, assembly, black/stainless, w/5 bushings
17	387174602	A B	Bracket, spring, cooktop mtg.
*	305376102	A B	Screw, (4)
19	318389600	A B	Bracket, conduit mtg.
20	5304518261	A B	Bracket, retainer, main top
*	305309606	A B	Screw, (2)
35	5304515130	A B	Bushing, knob, sealing
46	5304518262	A B	Box, cooktop, outer
* #	5304518264	A B	Box & wires assy
* #	5304518271	A B	Harness, wiring, main
*	202855101	A B	Holder, cable
*	318163601	A B	Cleaner-cooktop
*	305452800	A B	Screw, ground
*	305351200	A B	Rivet, 3, 2 x 6

WIRING DIAGRAM

