


**CENTER
CHANNEL**




STORY

SPEAKER

MANUAL

KLH



WELCOME!

Thank you for purchasing one of the best sounding speakers ever produced. At KLH, we have been making high-quality components since 1957, and we take pride in making your music and movies the best experience possible.

FOR YOUR SAFETY

Important Safety Instructions!

1. READ these instructions.
2. KEEP these instructions.
3. HEED all warnings.
4. FOLLOW all instructions.
5. DO NOT use this apparatus near water.
6. CLEAN with dry cloth.
7. DO NOT block any ventilation openings. Install in accordance with the manufacturer's instructions.
8. Do not install near any heat sources such as radiators, heat registers, stoves, or other heat producing appliances
9. ONLY USE attachments/accessories specified by the manufacturer.
10. DO NOT expose to excess moisture or liquids, and do not place containers with liquids on top of speakers.



The exclamation point, within an equilateral triangle, is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the product.



The lightning flash with arrowhead symbol within an equilateral triangle is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electrical shock to persons.



EU COMPLIANCE INFORMATION:

Eligible to bear the CE mark, Conforms to European Union EMC Directive 2004/108/EC; European Union Restriction of Hazardous Substances Recast (RoHS2) Directive 2011/65/EC; European Union WEEE Directive 2002/96/EC.

KLH and the KLH logo are registered trademarks of Kelley Global Brands Inc., registered in the U.S. and other countries.

WEEE NOTICE




Note: This mark applies only to countries within the European Union (EU) and Norway.



This appliance is labeled in accordance with European Directive 2002/96/EC concerning waste electrical and electronic equipment (WEEE). This label indicates that this product should not be disposed of with household waste. It should be deposited at an appropriate facility to enable recovery and recycling.


UNPACKING

Place the package on the floor or table top with the box flaps up. Cut the tape with a utility knife to open the package. Fold the carton flaps back and carefully slide the speaker and packaging from the box, or turn the box over with flaps open and remove the box. Stand the speaker and packing upright, making sure the speaker is right side up, and remove the packing material.



CONNECTING YOUR CENTER CHANNEL

The Story center channel has quality nickel-plated binding posts that will accommodate stripped wire, spade connectors or banana plugs. Be sure to use quality speaker cables, up to 12 gauge (AWG). The lowest gauge possible is recommended. Before using banana plugs, be sure to remove the black and red inserts on the binding posts. See the following diagrams in the AMPLIFICATION section for further instruction.




AMPLIFICATION

Conventional amplification involves a single stereo amplifier wired to a single set of binding posts with straps connecting the second set of posts as seen in diagram above. Simply attach the positive wire + to the red post, and the negative wire - to the black post.

ROOM POSITION


The placement of your center channel is very important in regard to home theater usage. The center channel produces most of the dialogue, and 60% of the total sound in a home theater application. It is recommended that the center channel speaker be placed below the viewing screen or monitor (see diagram).

The Story center channel speaker is sonically matched to work seamlessly with all other KLH speakers, and will deliver optimum performance in all home theater applications.



CENTER CHANNEL PLACEMENT


Place the center channel below the monitor in both wall mount and stand applications, as seen in the diagram below.



NOTE: When the center channel is positioned below ear level, it should be angled upward as seen in the diagram above.

PORT TUNING

If you are placing your center channel speaker 6 inches or closer to a wall, bass output can be controlled by reducing the amount of air flow from the rear ports. You can "tune" the bass output by using the room tuning stops provided with your speaker by inserting as shown.



WARRANTY

Our 10-year parts warranty begins from purchase date of the item (invoice date). For warranty/service issues, please contact your place of purchase. Please keep your original receipt. The warranty covers any production and material defects of product. Warranty registration may be completed at klhaudio.com/warranty

The following is NOT COVERED by the warranty:

1. Accidents, misuse, poor maintenance, electrical overloads such as lightning or voltage.
2. Repair must be performed by an authorized KLH dealer or service center
3. Incorrect installation of product.
4. Altered serial number.
5. Transportation costs for service call.
6. Purchase of KLH products from unauthorized reseller.

Replacement item cannot exceed the cost of the item under warranty. The supplier is responsible for only repair or replacement.

SPECIFICATIONS

Story Center Channel Speaker

Frequency response	48Hz-23kHz+/-3dB.
Sensitivity	91dB.
Power handling	200 watts.
Components	2 x 5.25" Woven Kevlar mid/bass drivers, and 1 high performance 1" Anodized Aluminum tweeters
Finishes	Walnut Wood Veneer or Black Oak Wood Veneer
Impedance	8Ω
Crossover point	2.4kHz.
Dimensions:	7" x 19" x 9.5" (H x W x D)
Weight:	16 lbs.



984 Logan Street, Suite 301
Noblesville, IN 46060
klhaudio.com