



Assembly Instruction

ITEM N0.: 8517BRW/GRY/PWT-1PW
Power Reclining Chair




Hardware are stored at the bottom of sofa, please take out it for assembly hardware for assembly.

Note: Do not use power tools for assembly. Power tools increase the risk of over tightening which lead to splitting or cracking the wood.


Component list

No	Drawing	Qty	Description
A	A line drawing of a rectangular seat cushion with a small circular hole on the left side.	1	SEAT
B	A line drawing of a rectangular backrest cushion.	1	BACK REST
C	A line drawing of a power cord with a standard two-pronged plug at one end.	1	PLUG
D	A line drawing of a rectangular power adaptor with a power cord attached.	1	ADAPTOR


Step #1



Step #2



Step #3



Care Instruction for Polished Microfiber Fabric Furniture:

In order to maintain the original appearance of your Polished Microfiber Fabric Furniture, please follow below simple care procedures:

- Avoid exposing furniture directly to sunlight or heating and air conditioning outlets. Sunlight and or exposure to heating and air conditioning outlets will fade/damage Polished Microfiber Fabric.
- Vacuum or wipe with a soft cloth to remove dust.



For items use on wooden floor, hard surfaces or carpets, it is recommended to Install protective pads under all legs and supports to avoid/prevent from damages/scratches and discoloration.