


ASSEMBLY INSTRUCTION FOR ACME FURNITURE




MODEL#LV03700

Thank you for purchasing the quality product. Be sure to check all packing material carefully for small parts which may have come loose inside the carton during shipment. Separate, identify and count all parts and metal hardware. Compare with all parts list to be sure all parts are present. If any part(s) are missing or damaged, please contact your local furniture dealer. For efficient and speedy service, please indicate the model number and code letter of part(s).

*****Do not fully tighten screws until fully assembled *****

COMPONENT PARTS			
DESCRIPTION	PART NAME		QTY (PCS)
①	LF ARM CHAIR		1
②	RF ARM CHAIR		1
③	METAL FEET		4
④	MIDFOOT		5

HARDWARE REQUIRED



Ⓐ		SCREW	M8*35	8	PCS
Ⓑ		TAPPING SCREW	φ5*40	8	PCS
Ⓒ		SPACER	M8*16MM	8	PCS
Ⓓ		SPACER	M5*10MM	8	PCS
Ⓔ		INNER HEXAGON SPANNER		1	PCS

Attention


***Some number parts listed on the instruction sheet may not be in parts bag as they may already be assembled. Carefully check parts and packing materials prior to ordering replacements.

How to assemble:


STEP 1 Attaching Multiple Units




VIEW FROM BELOW



Detaching Multiple Units



A
LIFT
LEVER
ELEVAR



How to assemble:

STEP 2

