

CROSLEY FURNITURE

Round Bar Cart CF4009



PART LIST




HARDWARE LIST

#1	#2	#3	#4
1/4" x 3/4"L			
1/4 X 5/4 E			
Bolt 16 PCS (Extra 1)	Allen Wrench 1 PC	Wrench 1 PC	Suction Cup Extra 2 PCS


Step 1. Lay side frame (part C) on a soft flat surface, such as carpet, as shown below. Attach shelf frames (part B) to side frame (part C) using bolts (part #1) and allen wrench (part #2).

NOTE: Please do not fully tighten bolts at this time.



Step 2. Attach top frames (part A) to side frame (part C) using bolts (part #1) and allen wrench (part #2).


NOTE: Please do not fully tighten bolts at this time.






Step 3. Attach legs (part D) to top frames (part A) and shelf frames (part B) using bolts (part #1) and allen wrench (part #2).

NOTE: Please fully tighten all bolts at this time.





Step 4. Attach locking casters (part F) and casters (part G) to side frame (part C) and legs (part D) using wrench (part #3).



Step 5. Carefully turn assembled unit upright, attach glass (part E) to shelf frames (part B).

