

E-Commerce by Enitial Lab


ASSEMBLY INSTRUCTIONS

MODEL#

CM3143PT-5PK

Questions?

GIVE US CALL: 1-888-980-5122 MON-FRI 8:30AM - 5:30PM (PST)



TOOLS REQUIRED



Allen Wrench

(Included)



Philip Screwdriver

(Not Included)



2 - People Recommended

ASSEMBLY RATING



The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.

VERSION #21-03-25





Thank you for your purchase!

We hope you enjoy this new addition to your home for many years to come.

Our commitment to providing quality products does not simply end when you purchase our product. We fully stand behind our products from start to finish. Our customer service department is available Monday – Friday 8:30 AM – 5:30 PM Pacific and can help with assembly questions as well as, if necessary, replacing damaged or missing parts. To help expedite our service, please have these assembly instructions readily available, along with your order receipt.



Consumer Hotline Toll-Free 1-888-980-5122



WEBSITE www.foagroup.com









foagrou



Monday to Friday 8:30AM- 5:30PM (PST)



E-MAIL cs.ec@foagroup.com



FurnitureOfAmerica

hardware together to make assembling easier.



Are you missing anything?

Double-check all parts, hardware and accessories listed on Page 6 are accounted for.

Check out our Quick Tips!

We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!

Prep Time!

Please review the assembly instructions and all diagrams prior to assembling. Arrange parts as recommended on Page 7 and group identical

PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.





Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.





Suitable Location

Assembling near the area of the intended location is highly recommended.





Sufficient Space

Make sure you have enough space to move around during the assembly.





Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent scratches.





Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.

ASSEMBLY AND CARE ADVICE




FAILURE TO FOLLOW THE GUIDELINES BELOW MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.



Position each part correctly and insert screws or bolts into their respective holes.



Use the appropriate hand tools or power tools for assembly. Select steps, such as tightening screws and/or bolts, may require hand tools to avoid causing damage during assembly.



Turn clockwise to tighten and only tighten when step is completed or when instructed to do so.



Save the instructions and store any supplied tools for later maintenance.




After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.

TABLE CM3143PT-5PK



- Please keep instructions for future reference.
- Check the quantity and irregularity of parts and hardware before you start.



PARTS





Table Top





Table Legs

HARDWARE















Bolt Ø5/16" x 2"-1/4"




Lock Washer Ø5/16"



Flat Washer








Align table legs (#2) to the table top (#1), then secure by using bolts (#A) with washers (#B,C).

Part x1pc
Part x4pcs
Hardware x8pcs
Hardware x8pcs
Hardware x8pcs
Hardware x8pcs
Hardware x8pcs


2



CHAIR CM3143PT-5PK



- Please keep instructions for future reference.
- Check the quantity and irregularity of parts and hardware before you start.



PARTS









Backrest









Chair Seat







Front Stretcher

Stretcher(R/L)

HARDWARE

#A 4pcs x4















Bolt Ø5/16" x 3-1/4"

Bolt Ø5/16" x 2"-1/4"

Bolt Ø5/16" x 1-1/2"

Screw #8x35mm














Lock Washer Ø5/16"

Flat Washer Ø5/16"

Allen Wrench 5mm

Exploded View



#G

1

Part #1 x1pc


Part #2 x1pc

Hardware#C x2pcs

Hardware#E x2pcs

Hardware#F)x2pcs

Align seat (#2) to the chair back (#1), then secure the middle holes by using bolts (#C) with washers (#E,F).




2

Hardware#A x4pcs

Hardware#E x4pcs

Hardware#F x4pcs

Secure corner holes of the seat (#2) to chair back (#1) by using bolts (#A) with washers (#E,F).




x4


x4

Align stretchers (#5R/L) to the Part #5 x2pcs chair back (#1). **x4** #5R #1 < #5L Part #3 x2pcs Align front legs (#3R/L) to the stretchers (#4,5R/L) and seat Part #4 x1pc (#2), then secure the front legs Hardware#B x4pcs (#3R/L) to the seat by using bolts Hardware #E) x4pcs (#B) with washers (#E,F). Hardware#F)x4pcs #3R #3L #5R #5L

5



6



ASSEMBLY COMPLETED



Please ensure the furniture rests on an even and flat surface. If the product wobbles or feels loose, double-check all bolts and/or screws are properly tightened and secured.

⊘ Keep this handy!

Please retain this instruction manual and any order-related information for future reference.

✓ Lift, don't drag!

To avoid damage to product please always LIFT the product when transporting of adjusting the placement.