




UTTERMOST


# Assembly Instruction

ITEM NO.: 24491

## Parts list

1	Table top	1pc
2	Base	1pc

ITEM	PART NAME	QTY
A	Allen wrench 	1 pc
B	Bolt 	4 pcs
C	Lock washer 	4 pcs
D	washer 	4 pcs



1. Turn the tabletop face down on a clean soft surface to avoid scratching the top of the table.
2. Attach the base to the table top corners, using flat washers D, lock washers C and bolt B then tighten with wrench E., Then tighten the Bolt B with A wrench .
3. Turn the assembled table to the upright position and the assembly is complete.

To Clean, wipe with soft dry cloth.

PO BOX 558/3325 GRASSY HILL RD. ROCKY MOUNT, VIRGINIA 24151  
[www.uttermost.com](http://www.uttermost.com)