















ASSEMBLY INSTRUCTIONS

9300060/9300106
Anderson KD 3 Tier Bookcase

A		B		C		D	 x12 M6x45mm	E	 x12 M6x30mm	F		G		H		I		
	X2		X6		X3						X2		X2		X2			



CAUTION:
PLEASE MAKE SURE THAT ALL PARTS ABOVE ARE FIXED TIGHT AND FIRM BEFORE USE.
THIS PRODUCT IS DESIGNED AS A SEAT FOR INDOOR USE ONLY.
DO NOT STAND ON THIS PRODUCT IN ANY CIRCUMSTANCE