



ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

115502
Side Chair

ITEM: 115502

COASTER
FINE FURNITURE

ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

15 MINUTES

PARTS IDENTIFICATION

A SEAT AND BACK




1PC

B FRONT LEG



2PCS


C BACK LEG



2PCS

HARDWARE IDENTIFICATION

1 SHORT BOLT
(5/16" x 50mm - BLK)



4PCS

2 LONG BOLT
(5/16" x 75mm - BLK)



4PCS

3 LOCK WASHER
(1.6 x 14mm - BLK)



8PCS

4 FLAT WASHER
(2 x 19mm - BLK)



8PCS

5 ALLEN WRENCH
(M5 x 65mm - BLK)




1PC



ITEM:115502
ASSEMBLY INSTRUCTIONS

COASTER
FINE FURNITURE

STEP 1




STEP 2
COMPLETE



ITEM: 115502

COASTER
FINE FURNITURE



Note: Dimension tolerance $\pm 5\%$