

BRAVOS XL
steam

MCT Maytag Commercial Technology



Appearance may vary depending on model.


Quick Start Guide

Top-Loading High Efficiency Low-Water Washer


1 SORT AND LOAD LAUNDRY



2 ADD HE DETERGENT & LAUNDRY PRODUCTS TO DISPENSERS*



Remove inside tray for powder HE detergent.



Follow manufacturer's instructions to determine amount of laundry products to use.




3 TOUCH POWER TO TURN ON THE WASHER




4 SELECT THE DESIRED CYCLE FOR YOUR LOAD*




5 ADJUST CYCLE SETTINGS, IF DESIRED*



6 SELECT ADDITIONAL OPTIONS*



7 TOUCH AND HOLD START/PAUSE TO BEGIN CYCLE



* **NOTE:** Not all cycles, settings or options are available with all models. Read "Cycle Guide" in Use and Care Guide before using washer for more information on your model's options and features.

W10740599A
W10740600A - SP

®/™ ©2014 Maytag. All rights reserved. Used under license in Canada.

11/14
Printed in U.S.A.

BRAVOS XL
steam

MCT Maytag Commercial Technology



Guide de démarrage rapide


L'aspect peut varier selon le modèle.

Laveuse à chargement frontal à haute efficacité et à faible consommation d'eau


- 1** TRIER, PUIS CHARGER LE LINGE DANS LA LAVEUSE



- 2** AJOUTER LE DÉTERGENT ET LES PRODUITS DE LESSIVE HE DANS LES DISTRIBUTEURS*



Retirer le plateau intérieur pour le détergent en poudre HE.




Suivre les instructions du fabricant pour déterminer la quantité de produits de lessive à utiliser.



- 3** APPUYER SUR POWER (MISE SOUS TENSION) POUR METTRE LA LAVEUSE EN MARCHÉ




- 4** SÉLECTIONNER LE PROGRAMME SOUHAITÉ POUR LA CHARGE*




- 5** AJUSTER LES RÉGLAGES DU PROGRAMME SI DÉSIRÉ*



- 6** SÉLECTIONNER TOUTE OPTION SUPPLÉMENTAIRE*



- 7** APPUYER SANS RELÂCHER SUR START/PAUSE (MISE EN MARCHÉ/PAUSE) POUR DÉMARRER LE PROGRAMME



***REMARQUE :** Certains programmes, réglages et options ne sont pas disponibles sur certains modèles. Lire le "Guide des programmes" et le Guide d'utilisation et d'entretien avant d'utiliser la laveuse pour plus d'informations sur les options et les caractéristiques de votre modèle.

W10740599A
W10740600A - SP

®/™ ©2014 Maytag. Tous droits réservés. Emploi sous licence au Canada.

11/14
Imprimé aux É.-U.