











Parliament Wall PARTS SHEET



ZPAR-1772 Parliament 72" TV Console
 ZPAR-3001 Parliament Bookcase Pier
 ZPAR-3003 Parliament Bridge & Back Panel

NO.	ZPAR-3003
01	 CROWN
02	 LEFT SIDE BACKING
03	 LEFT CENTER BACKING
04	 RIGHT CENTER BACKING
05	 RIGHT SIDE BACKING
ZPAR-3003 hardware	
A	 LOCK WASHER / FLAT WASHER / BOLT
B	 ALLEN WRENCH

NO.	ZPAR-3001
06	 TOP SHELF
07	 DOOR COMPLETE
08	 BOTTOM SHELF
hardware	
A	 DOOR HINGE
B	 ADJUSTABLE LEVELER
C	 SHELF HOLDER
D	 ROLLER CATCH
E	 ROLLER CATCH

NO.	ZPAR-1772
09	 SIDE DRAWER
10	 MIDDLE DROP DOWN DRAWER
11	 SIDE COMPLETE
12	 WOOD SHELF
13	 MIDDLE GLASS DOOR COMPLETE
14	 MIDDLE GLASS DOOR FRAME
15	 GLASS DOOR PANEL
16	 GLASS SHELF
17	 BACK RAIL
hardware	
A	 DOOR HINGE
B	 ADJUSTABLE LEVELER
C	 SHELF HOLDER
D	 ROLLER CATCH
E	 ROLLER CATCH
F	 DRAWER GLIDE

Thanks for choose Legends furniture