

E-Commerce by Enitial Lab

ASSEMBLY INSTRUCTIONS

MODEL#

CM3727T

Questions?


GIVE US CALL: 1-888-980-5122 MON-FRI 8:30AM - 5:30PM (PST)

TOOLS REQUIRED



Allen Wrench

(Included)





2 - Persons Recommended

ASSEMBLY RATING



EASY - DIFFICULT

The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.

VERSION # 20-12-02





Thank you for your purchase!

We hope you enjoy this new addition to your home for many years to come.

Our commitment to providing quality products does not simply end when you purchase our product. We fully stand behind our products from start to finish. Our customer service department is available Monday – Friday 8:30 AM – 5:30 PM Pacific and can help with assembly questions as well as, if necessary, replacing damaged or missing parts. To help expedite our service, please have these assembly instructions readily available, along with your order receipt.



Consumer Hotline Toll-Free 1-888-980-5122



WEBSITE www.foagroup.com







Monday to Friday 8:30AM- 5:30PM (PST)



E-MAIL cs.ec@foagroup.com





Are you missing anything?	Check out our Quick Tips!
Double-check all parts, hardware and accessories listed on Page 6 are accounted for.	We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!
Should we send any replacements?	Prep Time!
Are there any irregularities or flaws in the parts? We can send replacements!	Please review the assembly instructions and all diagrams prior to assembling. Arrange parts as recommended on Page 7 and group identical hardware together to make assembling easier.

PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.





Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.





Suitable Location

Assembling near the area of the intended location is highly recommended.





Sufficient Space

Make sure you have enough space to move around during the assembly.





Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent scratches.





Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.

ASSEMBLY AND CARE ADVICE



FAILURE TO FOLLOW THE GUIDELINES BELOW MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.



Position each part correctly and insert screws or bolts into their respective holes.



Use the appropriate hand tools or power tools for assembly. Select steps, such as tightening screws and/or bolts, may require hand tools to avoid causing damage during assembly.



Turn clockwise to tighten and only tighten when step is completed or when instructed to do so.



Save the instructions and store any supplied tools for later maintenance.




After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.





- · Please keep instructions for future reference.
- Check the quantity and irregularity of parts and hardware before you start.



PARTS





#3 2pcs







Glass Top


Base

Support Leg

HARDWARE









Adjuster Ø1/4" x 1/2"





Bolt Ø1/4" x 1-1/4"





Allen Wrench





Flat Washer

CM3727T is packed in 2 cases

Carton	Disignation		Part	Hardware
CM3727T-1	Glass Top	#1		
CM3727T-2	Base	#2		#A 4pcs #B 8pcs #C 8pcs #D 4pcs
010101211-2	Support Leg	#3	2pcs	#E 1pc

ASSEMBLY INSTRUCTIONS

1


Part #1) x1pc

Part #3 x2pcs

Hardware #A x4pcs

Hardware #E x1pc

- I. With the help of another person, carefully place the glass top (#1) facing down on a protected surface.
- II. Align the 2 legs (#3) with the pre-drilled holes on the bottom of the glass top (#1).
- III. Insert 4 screws (#A)
 through the 2 legs (#3)
 and secure those screws
 using the Allen wrench
 (#E) to lock them with the
 glass top (#1).



ASSEMBLY INSTRUCTIONS

2

Part #2 x1pc


Part #3 x2pcs


Hardware (#B) x8pcs

Hardware (#C) x8pcs

Hardware (#D) x4pcs

Hardware (#E) x1pc





- I. Align the base (#2) with the predrilled holes of the 2 legs (#3).
- II. Prepare 8 bolt assemblies by inserting the lock washer (#C) onto the screw (#B).
- III. Insert the bolt assemblies through the pre-drilled holes from the bottom of the base (#2) and secure those screws using the Allen wrench (#E) to lock them with the legs (#3).
- IV. Align the threaded end of the 4 glides (#D) with the pre-drilled holes on the bottom of the base (#2) and tighten by hand until secured.
- V. With the help of another person, carefully place the table in upright position. Make sure the table is rested on a flat surface and does not feel loose or wobbly. If it does, double check that the bolts/screws are secured and properly tightened.

ASSEMBLY COMPLETED



Please ensure the furniture rests on an even and flat surface. If the product wobbles or feels loose, double-check all bolts and/or screws are properly tightened and secured.

✓ Keep this handy!

Please retain this instruction manual and any order-related information for future reference.

Lift, don't drag!

To avoid damage to product please always LIFT the product when transporting of adjusting the placement.