




Parker Living  
A Division of Parker House

## Assembly Instructions Penfield Sofa

### BEFORE ASSEMBLY









Thank you for purchasing this quality product. This product has been designed for easy assembly and constructed for durability. Please take the time to read and follow the assembly instructions carefully.

### Power Sofa




### Part List

When unpacking, please be careful not to discard any parts with the packaging. Before continuing, please make sure you have the following parts:

No	Description	Sketch	Qty
A	Body		1 PC
B	LAF Back Cushion		1 PC
C	Middle Back Cushion		1 PC
D	RAF Back Cushion		1 PC
E	LAF Wing		1 PC
F	RAF Wing		1 PC
G	Wall plug transformer		1 PC
H	Remote		1 PC

## Step 1

Before removing the product from the carton, detach and remove the plywood from the frame using screw driver as shown in the diagram.



Screws' dim:5x80mm


## Step 2

There are two wings under seats. Remove LAF Wing(E) and RAF Wing(F) from under seat. Meanwhile, untie the wall plug transomer(G) .

G  
Wall plug transomer






H Remote





## Step 3

1. Install the Backrest(B/C/D) into the Seat(A) by positioning the female metal receiver brackets over the male metal posts. Ensure that female metal receiver brackets on each side of the backrest are line up with the seat metal posts. Push down the female brackets over male posts simultaneously until each side is locked into place and an audible “ click ” is heard.
2. Install the LAF Wing(E) and RAF Wing(F) into by sliding wing in a downward motion along the side of the seat back to connect the brackets.
3. Connect the wire. A wire with yellow label for headrest motor connect with yellow, C wire in green label for seat motor connect with green, B in round shape for heat massage and hand control.
4. Attach the flap to the seat frame by pulling the flap down, and pressing the bottom hem under the seat base , connecting the velcro.



1.





2.



3.



4.





Seat contains 2.2 Density Foam, Back Cushion contains 100% Fiber.

## Power Connection

Connect firmly one end of the wall plug transformer cord into the DC adapter located in the lower back corner of Recliner and plug the other end into a power outlet/wall socket and enjoy.

**Note:** After all connections made, the green LED will be lit up and it will announce "power on" for speaker. Enable bluetooth on your mobile device and select "speaker" from the list. A voice prompt will say "connected" to confirm a successful pairing.



## Speaker Setup Guide:

- 1. Power Up:** Connect the power cable to the product and plug it into an outlet. It will announce "power on" when connected.
- 2. Pairing:** Enable Bluetooth on your mobile device or smart TV and scan for available devices. Select "SPEAKER" from the list.
- 3. Connection Confirmed:** A voice prompt will say "connected" to confirm a successful pairing.
- 4. Enjoy !** You can now play any music or video on your device. Adjust the volume directly on your device as needed.

## Troubleshooting:

- Turn off the headphone safety function on your device to achieve maximum volume.
- Connect to multiple SPEAKERS by pairing to one, and the nearby SPEAKERS will sync.
- Use a Bluetooth receiver for non-smart TVs.

## **Speaker Setup Guide:**

- 1. Power Up:** Connect the power cable to the product and plug it into an outlet. It will announce "power on" when connected.
- 2. Pairing:** Enable Bluetooth on your mobile device or smart TV and scan for available devices. Select "SPEAKER" from the list.
- 3. Connection Confirmed:** A voice prompt will say "connected" to confirm a successful pairing.
- 4. Enjoy !** You can now play any music or video on your device. Adjust the volume directly on your device as needed.

## **Troubleshooting:**

- Turn off the headphone safety function on your device to achieve maximum volume.
- Connect to multiple SPEAKERS by pairing to one, and the nearby SPEAKERS will sync.
- Use a Bluetooth receiver for non-smart TVs.