


ITEM: 6952-75906-85 Display Cabinet

Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.


Read all instruction and study the drawing carefully before starting the assembly process.

HARDWARE PACK				
NO.	DRAWING	DESCRIPTION	SIZE	Q'TY
Α		Allen Wrench	69*27.2*4mm	1 PC
В		Bolt	1/4*25mm	2 PCS
С	0	Lock Washer	1/4(6mm)	2 PCS
D	0	Flat Washer	1/4*16mm	2 PCS
E		Hanger	75*30*38mm	2 PCS
F	1	Screw	8*11/4	2 PCS
G		Plastic Anchor		2 PCS
Н	Ø	Anti-Tip Kit		1 PC
ı	\$	Open Wrench	8mm/70mm	1 PC



Mount the hanger (E) to top of the cabinet, then attach the

cabinet to a wall.



Note: Anti-tip kit restraint is provided.





ITEM: 6952-75906-85 Display Cabinet

Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.

Read all instruction and study the drawing carefully before starting the assembly process.

Anti-tip kit is included for use. We recommend installing for






Note: Anti-tip kit restraint is provided.



ITEM: 6952-75906-85 Display Cabinet

Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.

Read all instruction and study the drawing carefully before starting the assembly process.



Assembly Steps

- 1. When each piece of cabinet is used alone, attach male connector of the power switch (A) to a wall plug. (See Diagram 1)
- 2. Touch dimmer is at the inside of right post.
- 3. If you want to bunch two or more cabinets together, place them all side by side in a desired location.
- 4. Leave male connector of the puck light (C) and female connector of power switch (B) for the first cabinet (#1) as it is. Keep male connector of the puck light (C) and female connector of power switch (B) off for the rest cabinets (#2, #3, and so on). (See Diagram 2)


Note: Anti-tip kit restraint is provided.



ITEM: 6952-75906-85 Display Cabinet

Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.

Read all instruction and study the drawing carefully before starting the assembly process.



Assembly Steps

- 5. Connect female connector of the puck light (D) (#1 cabinet) with male connector of power wire (E), then have female connector of power wire (F) connected to male connector of puck light (C) (the #2 cabinet). (See Diagram 3)
- 6. Repeat step 5 for the 3rd cabinet and the rest ones when more than two are bunched together till each one is connected.
- 7. Plug in male connector of power switch (A) (#1 cabinet).
- 8. Touch the dimmer of the #1 cabinet, all puck lights connecting together will be on at the same time.

Note: Anti-tip kit restraint is provided.




ITEM: 6952-75906-85 Display Cabinet

Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.

Read all instruction and study the drawing carefully before starting the assembly process.

Hinge Replace Instruction:

When the door hinge is damaged, use the Open Wrench (I) to unscrew the hardware and replace with the new hinge.



Note: Anti-tip kit restraint is provided.