

WINNERS ONLY®

ASSEMBLY INSTRUCTIONS

PROD. NO: AU300SW /AU300SN

Thank you for purchasing this quality product. Please read the instructions thoroughly before unpacking the assembly parts.





Caution : Sharp exposed staple tips can cause injury, therefore for your protection, please remove any exposed staples used in packing.

Please keep all hardware parts out of the reach of children.


1. We recommend that you should assemble this product with assistance of another person; this will make the assembly easier, and will help to prevent personal injury and to insure parts are not damaged during the assembly process.
2. Before beginning, please check the packing materials carefully for small parts which may have come loose inside the carton during shipping. Please do not discard any packing material until all parts have been located. If any parts are missing, please contact your dealer for prompt replacement.
3. To prevent damage to your floor or carpet, please check the bottom of each piece of furniture for stain residues and rough surfaces and also check for staples or nails left after removing the packing materials. The manufacturer will not be held responsible if preventive steps are not taken prior to installation.
4. Please do not over tighten screws or bolts. During normal use everyday, screws, bolts, nuts, and wooden plugs may loosen up. They should be periodically inspected and re-tightened to prevent damage to the furniture and (or) personal property or cause injury. Always check to be sure all hardware on this list and the below mentioned components are attached to the furniture properly and kept tightened.
5. Please lay all parts and hardware on a non abrasive surface such as carpet, and follow the assembly.

This product will take 25-30 minutes to assemble

Components List:

NO	DESCRIPTION	SKETCH	QTY
A	TABLE TOP		1 PC
B	TABLE LEG (L)		2 PCS
C	TABLE LEG (R)		2 PCS
D	H SIDE RAIL		2 PCS
E	H CENTER RAIL		1 PC

Hardware List:

NO	DESCRIPTION	SIZE	SKETCH	QTY
1	JCBB BOLT WITH WASHER	M8 X 60mm		8 PCS
2	ALLEN KEY	M5		1 PC
3	JCBC BOLT WITH WASHER	M6 X 40mm		2 PCS
4	ALLEN KEY (BALL SHAPE)	M4		1 PC
5	FH SCREW	#8 X 32mm		4 PCS

TIP: store the Allen key and or Wrench used in assembly in this product's drawer or use masking or painter's tape to affix it to the underside of the product. This will make it easier to find if you want to periodically tighten bolts or disassemble the product.

WINNERS ONLY®

ASSEMBLY INSTRUCTIONS

PROD. NO: AU300SW / AU300SN

FIG 1.2





FIG 1.1



Step 1.1 Attach H Centre Rail (E) via pre-installed wood dowel at both H Side Rail (D) as shown on FIG 1.1.

Step 1.2 Insert JCBC Bolt with washer (3) through the hole on H Center Rail (E) and tighten by using Allen Key (4) to screw into the hole on both H Side Rail (D) as shown on FIG 2.

Note : Please do not fully tighten the bolts.

FIG 2.2





FIG 2.1



Step 2.1 Turn Table Top (A) upside down on a soft protective surface such as carpet. Please make sure Table Leg (C) has a small hole for identification as shown on FIG 2.1 before start assembly.

Step 2.2 Attach Table Leg (B) and Table Leg (C) to corner of Table Top (A) using JCBB Bolt with washer (1) and Allen Key (2) as shown on FIG 2.2.

Note : Please do not fully tighten the bolts.

FIG 3.1





FIG 3.2



Step 3.1 Align H Side Rail (D) & H Center Rail (E) to the designated hole at Table Leg (B & C) as shown on FIG 3.1.

Step 3.2 Please make sure Table Leg (C) has a small hole for identification as shown on FIG 3.2.

FIG 4.2





FIG 4.1



Step 4.1 Secure Table Leg (B & C) using JCBB Bolt with washer (1) and Allen Key (2) as shown on FIG 4.1.

Step 4.2 Tighten H Center Rail (D) to Table Leg (B & C) with Screw (5) as shown on FIG 4.2.

Note: Please fully tighten all the bolt and screws now.

Assembly is now complete.

2 OF 2

WINNERS ONLY®

ASSEMBLY INSTRUCTIONS

PROD. NO: AU300SW /AU300SN

Thank you for purchasing this quality product. Please read the instructions thoroughly before unpacking the assembly parts.





Caution : Sharp exposed staple tips can cause injury, therefore for your protection, please remove any exposed staples used in packing.

Please keep all hardware parts out of the reach of children.

1. We recommend that you should assemble this product with assistance of another person; this will make the assembly easier, and will help to prevent personal injury and to insure parts are not damaged during the assembly process.
2. Before beginning, please check the packing materials carefully for small parts which may have come loose inside the carton during shipping. Please do not discard any packing material until all parts have been located. If any parts are missing, please contact your dealer for prompt replacement.
3. To prevent damage to your floor or carpet, please check the bottom of each piece of furniture for stain residues and rough surfaces and also check for staples or nails left after removing the packing materials. The manufacturer will not be held responsible if preventive steps are not taken prior to installation.
4. Please do not over tighten screws or bolts. During normal use everyday, screws, bolts, nuts, and wooden plugs may loosen up. They should be periodically inspected and re-tightened to prevent damage to the furniture and (or) personal property or cause injury. Always check to be sure all hardware on this list and the below mentioned components are attached to the furniture properly and kept tightened.
5. Please lay all parts and hardware on a non abrasive surface such as carpet, and follow the assembly.

This product will take 20-25 minutes to assemble

Components List:

NO	DESCRIPTION	SKETCH	QTY
A	LEG (L)		2 PCS
B	LEG (R)		2 PCS
C	STRETCHER		4 PCS
D	BOX SEAT		1 PC

Hardware List:

NO	DESCRIPTION	SIZE	SKETCH	QTY
1	JCBC BOLT WITH WASHER	M6 X 60mm		8 PCS
2	ALLEN KEY (BALL SHAPE)	M4		1 PC
3	FH SCREW	#8 X 32mm		8 PCS

TIP: store the Allen key and or Wrench used in assembly in this product's drawer or use masking or painter's tape to affix it to the underside of the product. This will make it easier to find if you want to periodically tighten bolts or disassemble the product.

WINNERS ONLY®

ASSEMBLY INSTRUCTIONS

PROD. NO: AU300SW / AU300SN

FIG 1.2






FIG 1.1



Step 1.1 Turn Box Seat (D) upside down on a soft protective surface such as carpet. Please make sure Leg (A) has a small hole for identification as shown on FIG 1.1 before start assembly.

Step 1.2 Secure Leg (A) to Box Seat (D) using JCBC Bolt with washer (1) and Allen Key (2) as shown on FIG 1.2.

Note : Please do not fully tighten the bolts.

FIG 2.3




FIG 2.1






FIG 2.2



Step 2.1 Align Stretcher (C) to the designated hole at Leg (A) as shown on FIG 2.1.

Step 2.2 Align Leg (B) to pre-assembly of Stretcher (C) in Step 2.1 and attach Leg (B) to Box Seat (D) using JCBC Bolt with washer (1) and Allen Key (2) as shown on FIG 2.2.

Step 2.3 Attach Stretcher (C) to Leg (A & B) using Screw (3) as shown on FIG 2.3.

Note : Please do not fully tighten the bolts.

FIG 3.3




FIG 3.1




FIG 3.1





FIG 3.2




Step 3.1 Repeat Step 2.1 for the other Stretcher (C) as shown on FIG 3.1.

Step 3.2 Align Leg (B) to pre-assembly of Stretcher (C) in Step 3.1 and attach Leg (B) to Box Seat (D) using JCBC Bolt with washer (1) and Allen Key (2) as shown on FIG 3.2.

Step 3.3 Attach Stretcher (C) to Leg (A & B) using Screw (3) as shown on FIG 3.3.

Note : Please do not fully tighten the bolts.



Step 4 Turn the barstool to standing position. Check the barstool for balance and tighten all the bolts to complete the assembly.

Assembly is now complete.

2 OF 2