

POLYWOOD

Assembly Instructions



20-year warranty

View our full warranty:
polywoodoutdoor.com/warranty



Having trouble?

If you have questions or concerns regarding assembly instructions or missing parts, please contact us at hello@polywoodoutdoor.com or (833) 665-6300



Cleaning tips

For a Quick Clean:


Simply wipe down with soap and water.

For a Deep Clean:

Wipe on $\frac{1}{3}$ bleach and $\frac{2}{3}$ water solution with a clean cloth and let it sit on the lumber for a few minutes (this will not affect the color). Then, loosen any dirt and debris that may catch in surface grooves with a soft bristle brush; hose down to rinse.

For a High-Power Clean:

Use a pressure power washer (not exceeding 1,500 psi) to spray off dirt and debris. Apply a $\frac{1}{3}$ bleach and $\frac{2}{3}$ water solution and scrub with a soft-bristle brush. Hose down to rinse.



CLGNS604 60" Swing

Thank You

Thank you for choosing POLYWOOD!
We hope our furniture helps create a gathering place for you and your loved ones to enjoy for many years to come!



Reach Out

Let us know how we're doing:
hello@polywoodoutdoor.com
(833) 665-6300



Stay Connected

Be the first to hear about new products, giveaways, and more by signing up for our email list: polywoodoutdoor.com/subscribe



Watch & Learn

For assembly tips and videos visit:
polywoodoutdoor.com/assembly

Share your space

We love to see where our furniture ends up — snap a pic and tag it on Instagram or Facebook for your chance to be featured on our social channels!
#polywood #rethinkoutdoor



facebook.com/polywoodoutdoor




[@POLYWOOD](https://www.instagram.com/POLYWOOD)



pinterest.com/polywood



youtube.com/polywood




Did you know?


POLYWOOD was the original outdoor furniture made from recycled materials.

Learn more about our story:
genuinePOLYWOOD.com

TOOLS




4mm T-handle
hex key (included)



1/2" wrench
(not included)

PARTS


*Not to scale




A x2 **B** x4 **C** x2 **D** x2




1.75" Bolt — H.25-20X1.75




1.75" Screw — H.27X1.75




2" Screw — H.27X2



3" Screw — H.27X3



Eye Bolt — HEB5/16-18X1.5SS *




Eye Bolt - HS5/16x4.25SS *



Nut
HN5/16-18NLSS *



Washer
HW.31FLS *




Quick Link — HQL25ZN *

x4

x8


x6



Chain — HSC3/16EG-PROOF *

x4

1




Washer
HW.31FLS

x2




Nut
HN5/16-18NLSS

x1





Duplicate other side

2



3



Washer
HW.31FLS


x4



Nut
HN5/16-18NLSS


x2

4



Do not tighten until after step 5


5



6

Hanging mounts should be about
65" apart.


(Hanging Hardware not included)



x2

Adjust these chains for
height (9ft porch max)

Adjust these chains
for comfort



x4

Seat should measure
about 18" from floor