


Components and Hardware List


Console



(A)

1 pc.

Leg Frames



(B)

2 pcs.

Allen Head Bolt
Ø6 x 20mm



(H1)

8 pcs.

Lock Washer
Ø9 x Ø13mm



(H2)

8 pcs.

Flat Washer
Ø8 x Ø20mm



(H3)

8 pcs.

Allen Key
4 x 110mm



(H4)


1 pc.

Anti Tipping



(H5)

2 pcs.




#32640

Entertainment Console


Be sure to check all packing material carefully for small parts, which may have come loose inside the carton during shipment.

STEP 1




Tipping Restraint Hardware Kit
(Inside White Plastic Bag)

STEP 2



Adjustable leveler




(H3)

(H2)

(H1)

(H4)



Remove the screws to
adjust the shelf height.

For product and personal safety, Anti-Tip Restraint Kits have been included with this cabinet which can help to minimize the risk of the cabinet accidentally tipping forward, if used and properly installed