

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

205114
Mirror

ITEM: **205114**



ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME

10 MINUTES

PARTS IDENTIFICATION

A


MIRROR



1PC

B


DRESSER
FROM BOX ITEM
#205113



1PC

C

MIRROR SUPPORT
(PACKED WITH MIRROR)




2PCS

HARDWARE IDENTIFICATION

1


SHORT BOLT
(M6 x 35mm - BLK)



4PCS

2


LONG BOLT
(M6 x 40mm - BLK)



4PCS

3


LOCK WASHER
(1/4" - BLK)



8PCS

4


FLAT WASHER
(1/4"ID x 19mm - BLK)



8PCS

5

ALLEN WRENCH
(M4 x 60MM - BLK)



1PC


ITEM: **205114**



ASSEMBLY INSTRUCTIONS


STEP 1

ARROW MARKING FACE UPWARD



STEP 2

ARROW MARKING FACE UPWARD




ITEM: **205114**



ASSEMBLY INSTRUCTIONS


STEP 3



STEP 4 COMPLETE



ITEM: **205114**



Note: Dimension tolerance $\pm 5\%$