

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

936135 Accent Table

ITEM: 936135



ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

5 MINUTES

PARTS IDENTIFICATION

A ACCENT TABLE



1PC

B MAGAZINE HOLDER



1PC

C PEDESTAL COLUMN




2PCS

ITEM:**936135**


COASTER

ASSEMBLY INSTRUCTIONS


STEP 1




STEP 2



STEP 3



STEP 4 COMPLETE






PAGE 3 OF 3



Inner Size of Drawer: 12.25"W x 12.25"W x 1.25"H x 0.50"T



Note: Dimension tolerance ±5%