





INSTRUCTIONS:

TO ATTACH THE CASTERS TO THE TABLE

- 1.- INSERT THE POST OF THE CASTER INTO THE NUT INSERT AND PUSH FIRMLY

HARDWARE		
DESCRIPTION	# PCS	
CASTER	4	

PRODUCT IMAGE SHOWN IS FOR ILLUSTRATIVE PURPOSES ONLY, SHOULD NOT BE TAKEN AS REFERENCE POINT



ASSEMBLY INSTRUCTIONS

I-CKT-C001