

## ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



*Fine Furniture for every stage of life*

**980072**  
**WALL SHELF**

ITEM: **980072**



## ASSEMBLY INSTRUCTIONS

### ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



### WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.








ASSEMBLY TIME

25MINUTES

## PARTS IDENTIFICATION

<b>A</b>	<b>TOP LEFT POST</b>		<b>1 PC</b>
<b>B</b>	<b>TOP RIGHT POST</b>		<b>1 PC</b>
<b>C</b>	<b>BOTTOM POST</b>		<b>2 PCS</b>
<b>D</b>	<b>SHELF</b>		<b>6 PCS</b>

**ASSEMBLY INSTRUCTIONS****Z      HARDWARE IDENTIFICATION**


- |          |  |  |               |
|----------|--|--|---------------|
| <b>1</b> | <b>BOLT</b><br>( 1/4" x 15mm - BLK )           |    | <b>28 PCS</b> |
| <b>2</b> | <b>WAFER HEAD SCREW</b><br>( Ø8 x 26mm - BLK ) |    | <b>2 PCS</b>  |
| <b>3</b> | <b>PLASTIC ANCHOR</b><br>( Ø14 x 43mm - WHT )  |    | <b>2 PCS</b>  |
| <b>4</b> | <b>LEVELER</b><br>( Ø24 x 22mm - BLK )         |    | <b>2 PCS</b>  |
| <b>5</b> | <b>ALLEN WRENCH</b><br>( 4mm x 108mm - SR )    |  | <b>1 PC</b>   |

ITEM: **980072**


**COASTER**  
FINE FURNITURE

## ASSEMBLY INSTRUCTIONS

### STEP 1



### STEP 2




ITEM: **980072**


**COASTER**  
FINE FURNITURE

## ASSEMBLY INSTRUCTIONS

### STEP 3



### STEP 4





ITEM: **980072**




## ASSEMBLY INSTRUCTIONS

### **STEP 5**

**COMPLETE**



ITEM: **980072**



**Note :** Dimension tolerance  $\pm 5\%$