



Power
Reclining Sofa
2902-62M in 959-02

62M	FEATURES	
62H		
62		
60M		
60H		
601H		
60		
53		
51M		
51H		
51		
50M		
50H		
50		
	Flexsteel Spring Unit	
●	DualFlex	
	Back Construction	
●	Attached	
	Seat Construction	
●	Attached	
	Seat Cushion(s)	
●	High-Density (HC)	
	Tailoring	
○	Arm Covers	

- Standard
- Optional

PRODUCT DIMENSIONS	OVERALL			SEAT			Arm Height	Open Depth	Wall Clearance
	Height	Width	Depth	Height	Width	Depth			
Power Reclining Sofa -62M	42"	87"	40"	20"	73"	21"	26"	69"	7"
Power Reclining Sofa with Power Headrests -62H	42"	87"	40"	20"	73"	21"	26"	69"	7"
Reclining Sofa -62	42"	87"	40"	20"	73"	21"	26"	69"	7"
Power Reclining Loveseat -60M	42"	63"	40"	20"	48"	21"	26"	69"	7"
Power Reclining Loveseat with Power Headrests -60H	42"	63"	40"	20"	48"	21"	26"	69"	7"
Power Reclining Loveseat with Console & Power Headrests -601H	42"	76"	40"	20"	61"	21"	26"	69"	7"
Reclining Loveseat -60	42"	63"	40"	20"	48"	21"	69"	69"	7"
Swivel Gliding Recliner -53	41"	37"	40"	20"	22"	22"	25"	67"	15"
Power Rocking Recliner -51M	41"	37"	40"	20"	22"	22"	25"	67"	15"
Power Rocking Recliner with Power Headrest -51H	41"	37"	40"	20"	22"	22"	25"	67"	15"
Rocking Recliner -51	41"	37"	40"	20"	22"	22"	25"	67"	15"
Power Recliner -50M	41"	37"	40"	20"	22"	22"	25"	67"	5"
Power Recliner with Power Headrest -50H	41"	37"	40"	20"	22"	22"	25"	67"	5"
Recliner -50	41"	37"	40"	20"	22"	22"	25"	67"	5"

NOTES

Removable backs allow for easy lifting and maneuvering through doorways.
Only available in select fabrics.
Swivels a full 360 degrees.
Glides or redines from any swivel position.
Swivels in all directions while redined.
Lower the footrest by applying pressure to it in a downward motion. Lowering the footrest with the handle can damage the recliner.
Safety locks prevent the recliner from gliding while reclining.
Power mechanism allows you to smoothly recline to any position.
Single USB port is included on the power button control.
Safety locks prevent the recliner from rocking while reclining.
Safety locks prevent the furniture from gliding while reclining.
Safety locks prevent the furniture from rocking while reclining.
Power headrest mechanism allows you to adjust the headrest.
Two power buttons allow you to operate the reclining and headrest mechanisms independently.
Home button returns the headrest and footrest to their original positions.
Power allows you to smoothly recline to any position.
A single USB port is included on each power button control on styles with arms.
Power allows you to smoothly recline to any position and adjust the headrests.
Lower the footrest by applying pressure to it in a downward motion. Lowering the footrest with the handle can damage the recliner.