



## Whirlpool Model: WSES3330TB

30-inch Electric Range with No Preheat Mode and Slow Cook

Color  Black

### Product Description

Make the most of your time in the kitchen with this Whirlpool 30 inch electric range. Take preheating off your plate with No Preheat Mode, and heat up all day dishes with Slow Cook. Tackle your to-do list with features built for multitasking, boil 40% faster\* with FlexHeat™ Dual Radiant Elements, and add a toasty twist or melty magic to family classics with Broil. \*When comparing to the standard 6" element on the same unit.

### Specifications

#### Oven Cavity Details

Number of Oven Racks	2
Convection Functions	Bake Broil Keep Warm No Preheat Frozen Bake No Preheat Frozen Bake Slow Cook
Oven Rack Type	2 Standard
Broiler Location	Top Center
Oven Cleaning Type	Steam Clean
Door Removable	Yes
Number of Oven Lights	1
Convection Element Type	None
Oven Light Type	Halogen
Number of Rack Guides	5
Hidden Bake Element	Exposed
Oven Cooking System	Thermal
Broiler Element Power	3,400 W
Bake Element Power	2,400 W
Oven Rack Guide Type	Embossed
Automatic Convection	No
Oven Light Switch Location	Oven Control
Oven Rack Front Material	Metal
Temperature Probe	No
Temperature Sensor	Yes

#### Certifications

ADA Compliant	Yes
CUL	No
UL	Yes
Prop 65	
Energy Star® Qualified	Yes

#### Element/Burner Details

Center Rear Element-Burner	6in.
Center Rear Element-Burner	Warming
Center Rear Element-Burner	100W
Cooktop Element Style	Radiant
Left Front Element-Burner	3000W
Left Front Element-Burner	9in./6in.
Left Front Element-Burner	Dual
Left Rear Element-Burner	1200W
Left Rear Element-Burner	6in.
Left Rear Element-Burner	Single
Number of Cooking Element-	5
Right Front Element-Burner	3000W
Right Front Element-Burner	9in./6in.
Right Rear Element-Burner	6in.
Right Front Element-Burner	Dual
Right Rear Element-Burner	1200W
Right Rear Element-Burner	Single

**Details**

<b>Cooktop Configuration</b>	<b>All Burners</b>
<b>Delay Clean</b>	<b>No</b>
<b>Fuel Type</b>	<b>Electric</b>
<b>Installation Configuration</b>	<b>Freestanding</b>
<b>Oven Automatic Shut-Off</b>	<b>Yes</b>
<b>Oven Configuration</b>	<b>Single Oven</b>
<b>Power On Indicator Light</b>	<b>Yes</b>
<b>Power Outage Compatible</b>	<b>Yes</b>
<b>Range Configuration</b>	<b>Slide-In</b>
<b>Range Type</b>	<b>Slide-in</b>
<b>Air Fry</b>	<b>No</b>
<b>Oven Selections</b>	<b>Audible Signal</b> <b>Bake</b> <b>Broil</b> <b>Cancel/Off</b> <b>Clock</b> <b>Control Lock</b> <b>Convect Modes</b> <b>Cook Time Indicator</b> <b>Delay Start</b> <b>Keep Warm/Warm Hold</b> <b>Language Conversion</b> <b>No Preheat - Frozen</b> <b>Rapid Preheat</b> <b>Reheat</b> <b>Sabbath Mode</b> <b>Start Time</b> <b>Stop Time</b> <b>Timer</b>
<b>Literature Language</b>	<b>English</b> <b>French</b> <b>Spanish</b>
<b>Export Packaging</b>	<b>No</b>

**Exterior Details**

<b>Door Type</b>	<b>Glass</b>
<b>Oven Control Knob Type</b>	<b>N/A</b>
<b>Oven Control Location</b>	<b>Front</b>
<b>Oven Control Type</b>	<b>Tap Touch</b>
<b>Oven Window Size</b>	<b>Extra Large</b>
<b>Door Lock</b>	<b>Yes</b>

**Dimensions**

<b>Adjustable Height</b>	<b>Yes</b>
<b>Cutout Depth</b>	<b>24</b>
<b>Cutout Height</b>	<b>36</b>
<b>Cutout Width</b>	<b>30</b>
<b>Depth</b>	<b>25.4</b>
<b>Depth Closed Excluding</b>	<b>27.4</b>
<b>Depth Closed Including</b>	<b>29.1</b>
<b>Depth Excluding Doors</b>	<b>25.4</b>
<b>Depth With Door Open 90</b>	<b>47.7</b>
<b>Gross Weight</b>	<b>185</b>
<b>Height</b>	<b>36.6</b>
<b>Net Weight</b>	<b>169</b>
<b>Oven Interior Height</b>	<b>17.9</b>
<b>Oven Interior Depth</b>	<b>19</b>
<b>Oven Interior Width</b>	<b>24.2</b>
<b>Width</b>	<b>29.9</b>
<b>Capacity</b>	<b>5.3</b>
<b>Common Size</b>	<b>30</b>
<b>Maximum Height</b>	<b>38.1</b>
<b>Minimum Height</b>	<b>36.6</b>
<b>Console Language</b>	<b>English</b>

**Smart Compatibility**

<b>Connectivity</b>	<b>Amazon Alexa</b> <b>Android</b> <b>Google Assistant</b> <b>Nest</b> <b>iOS</b>
<b>Smart Appliance</b>	<b>Yes</b>
<b>Works With</b>	<b>App</b> <b>Bluetooth</b> <b>Remote Access</b> <b>Voice Controlled</b> <b>WiFi</b>

**Controls**

<b>Display Color</b>	<b>White</b>
----------------------	--------------

**Features**

<b>Range Features</b>	<b>ADA Compliant</b>
-----------------------	----------------------

**Cooktop Details**

<b>Cooktop Control Location</b>	<b>Front</b>
<b>Cooktop Control Knob Type</b>	<b>Plastic</b>
<b>Cooktop Control Type</b>	<b>Knobs</b>
<b>Cooktop Surface Material</b>	<b>Glass</b>
<b>Griddle Included</b>	<b>No</b>
<b>Heating Element On</b>	<b>Yes</b>
<b>Hot Surface Indicator Light</b>	<b>Yes</b>

## Key Features

No Preheat Mode  
Slow Cook  
Edge-to-Edge Glass Cooktop  
2 FlexHeat™ Dual Radiant Elements  
High Speed Preheat  
Steam Clean  
Broil  
Keep Warm Setting  
Warm Zone  
Storage Drawer  
Large Capacity Oven  
Front Control Design  
ENERGY STAR® Certified  
Sabbath Mode

## Electrical Requirements

Power Cord Included	No
Amps	40
Hz	60
Volts	208
Watts	12000

## UPC Listing

Model : WSES3330TB	UPC : 883049951348
Model : WSES3330TS	UPC : 883049951355
Model : WSES3330TW	UPC : 883049951331