



ASSEMBLY INSTRUCTIONS

COASTER FINE FURNITURE



Fine Furniture for every stage of life

610243
Glider Recliner

ITEM: **610243**



ASSEMBLY INSTRUCTIONS


ASSEMBLY TIPS:

- 1.Remove hardware from box and sort by size.
- 2.Please check to see that all hardware and parts are present prior to start of assembly.
- 3.Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

WARNING



- 1.Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2.This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME

5 MINUTES

PARTS IDENTIFICATION

A SEAT



1PC

B BACK



1PC

C LEFT ARM



1PC

D RIGHT ARM



1PC

HARDWARE IDENTIFICATION

1 **THREADED BOLT**
(Φ5/16")



4PCS

2 **NUT**
(Φ5/16""*90L)




4PCS


NOTE:

Phillips head screw driver is required in the assembly process ; however, manufacturer does not provide this item.


ITEM: **610243**
ASSEMBLY INSTRUCTIONS
STEP 1





STEP 2




STEP 3



STEP 4
COMPLETE



ITEM: **610243**



Note: Dimension tolerance $\pm 5\%$