

FLEXSTEEL[®]




W1151-834

Round Dining Table

IMPORTANT NOTE


Carefully remove all the parts from the carton and put them individually on a soft cloth to prevent damage to the parts.

We have taken great care in the design of this product and request that you carefully and accurately follow our assembly instructions to ensure proper set-up. We recommend at least two adults assemble this product.




Part List


Assembly Instruction 1/5




A. Table Top
1 piece



B. Legs
4 pieces



C. Bottom
2 pieces




D. Connecting Panel
1 pieces

Hardware List



1. Long Bolt
Ø5/16" * 63.5mm
8 pieces




2. Short Bolt
Ø5/16" * 35mm
18 pieces



3. Spring Washer
Ø5/16" * 1.5mm
26 pieces



4. Flat Washer
Ø5/16" * 19mm
26 pieces



5. Hex Key
4mm
1 piece



6. Dowel
Ø10*30mm
16 pieces


IMPORTANT NOTES

- Do not tighten up all the bolts until each part is properly assembled.
- Keep the Hex Key in a safe place as you may need to tighten up the bolts in the future.
- Use a soft cloth between these parts and the floor.
- We recommend this product be assembled by at least two adults

STEP 1

Remove the connecting panel (D) from table top (A) by loosening the 2pcs bolts. These 2pcs bolts are not needed for following assembly steps. (See Figure 1)


Figure 1



STEP 2

Place Bottom (C) upside down on a clean, smooth surface. Attach Bottom (C) with the Short Bolts (2), Spring Washers (3) and Flat Washers (4). Use Hex Key (5) to tighten the Short Bolts (2). (See Figure 2)


Figure 2



STEP 3

Place Wood Dowels (6) into the holes in the Legs (B). Stack the Bottom (C) onto the Legs (B) with the help of another person. Attach Bottom (C) to the Legs (B) with Long Bolts (1), Spring Washers (3), and Flat Washers (4), and tighten with Hex Key (5). (See Figure 3)


Figure 3



STEP 4

Carefully position the base, Bottom (C) and Legs (B), in an upright position. Place Wood Dowels (6) into the holes in the Legs (B). Stack the Connecting Panels (D) onto the Legs (B). Attach Connecting Panels (D) to the Legs (B) with Short Bolts (2), Spring Washers (3), and Flat Washers (4), and tighten with Hex Key (5). (See Figure 4.)


Figure 4



STEP 5

Place Table Top (A) and the base upside down on a clean, smooth surface with the help of another person. Attach Connecting Panels (D) to the Table Top (A) with Short Bolts (2), Spring Washers (3), and Flat Washers (4), and tighten with Hex Key (5). (See Figure 5.) Carefully position the table in an upright position with the help of another person.


Figure 5



STEP 6

Adjust the levelers on the legs until the furniture is leveled. (See Figure 6)

Figure 6



CARE INSTRUCTION

- To avoid scratches, do not place sharp or jagged objects directly on the table top.
- Do not place hot items directly on the tabletop.
- Use placements or trivets under hot items and coasters under beverages to prevent marks and stains.
- Avoid the use of harsh chemicals or abrasive cleaning materials.
- Wipe the table clean with a soft, dry cloth after each use.
- Wipe up spills quickly with a soft, dry cloth.

Flexsteel Industries, Inc.

For Parts or Customer Service, call toll-free: 1-888-415-3979

Monday-Friday 8:00-5:00 pm Central Time

Email: customersolutions@flexsteel.com

www.flexsteel.com