


E-Commerce by Enitial Lab

ASSEMBLY INSTRUCTIONS





MODEL #

CM3150T

Questions?

GIVE US CALL: 1-888-980-5122 MON-FRI 8:30AM - 5:30PM (PST)

TOOLS REQUIRED




(Included)



Phillips Screwdriver

(Not Included)



Wrench



2 - People Recommended





The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.






Thank you for your purchase!

We hope you enjoy this new addition to your home for many years to come.

Our commitment to providing quality products does not simply end when you purchase our product. We fully stand behind our products from start to finish. Our customer service department is available Monday – Friday 8:30 AM – 5:30 PM Pacific and can help with assembly questions as well as, if necessary, replacing damaged or missing parts. To help expedite our service, please have these assembly instructions readily available, along with your order receipt.



PRE ASSEMBLY

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.


















Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.

Suitable Location

Assembling near the area of the intended location is highly recommended.

Sufficient Space

Make sure you have enough space to move around during the assembly.

Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent scratches.


Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.

ASSEMBLY AND CARE ADVICE



FAILURE TO FOLLOW THE GUIDELINES BELOW MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.




IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.


DINING TABLE

CM3150T


- Please keep instructions for future reference.
 - Check the quantity and irregularity of parts and hardware before you start.



PARTS





Exploded View



ASSEMBLY INSTRUCTIONS

Part (#6) x1pc Part (#7) x2pcs Hardware (#A) x4pcs Hardware (#B) x4pcs Hardware (#C) x4pcs Align connected plates (#7) to the bottom rail (#6), then secure by using bolts (#A) with washers (#B,C).






Attach threaded studs (#E) to the bases (#4). Align table bases (#4) to the support and bottom rails (#5,6). Secure bottom rails (#6) to bases (#4) by using bolts (#A) with washers (#B,C). Secure support rail (#5) to the bases (#4) by using hex nuts (#F).

ASSEMBLY INSTRUCTIONS

3

Part #3 x2pcs Hardware #A x6pcs Hardware #B x6pcs Hardware #C x6pcs



4 Hardware#A x8pcs Hardware#B x8pcs

Hardware#C x8pcs

ASSEMBLY INSTRUCTIONS

5

6

Unlock the table top by turning lever at the bottom of the table, then extend the table top. Align table leaf (#2) to the center of the table.

