

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

122508 Counter Height Dining Table

REVISION 0: 08/25/2025

PAGE 1 OF 3

COASTERFURNITURE.COM

ASSEMBLY INSTRUCTION



ASSEMBLY TIPS:

- 1. Remove hardware form box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING:

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

15 MINUTES

PARTS IDENTIFICATION

A TOP



1PC

B LEG



4PCS

HARDWARE IDENTIFICATION

1 BOLT (Ø5/16" x 75mm - RBW)



8PCS

2 LOCK WASHER (Ø5/16" x 13mm - RBW)



8PCS

3 FLAT WASHER (Ø5/16" x 19mm - RBW)



8PCS

4 ALLEN WRENCH (M4 x 59mm - RBW)



1PC


NOTE:

Phillips head screw driver is required in the assembly process. However, manufacturer does not provide this item.

COASTER

ASSEMBLY INSTRUCTION

STEP 1




STEP 2 COMPLETE









Note: Dimension tolerance ±5%



ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

122509 Counter Stool

REVISION 0: 08/25/2025

PAGE 1 OF 3

COASTERFURNITURE.COM

ASSEMBLY INSTRUCTION



ASSEMBLY TIPS:

- 1. Remove hardware form box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING:

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

15 MINUTES

PARTS IDENTIFICATION

A SEAT AND BACK

B LEG FRAME

2PCS

C STRETCHER

2PCS

HARDWARE IDENTIFICATION

BOLT 6PCS 1 (Ø1/4" x 35mm - RBW) **LOCK WASHER** 2 6PCS (Ø5/16" x 13mm - RBW) **FLAT WASHER** 6PCS 3 (Ø5/16" x 19mm - RBW) **PAN HEAD SCREW** 4PCS (Ø4" x 28mm - RBW) **ALLEN WRENCH** 1PC 5 (M4 x 59mm - RBW)


NOTE:

Phillips head screw driver is required in the assembly process. However, manufacturer does not provide this item.


ASSEMBLY INSTRUCTION

COASTER


STEP 1




STEP 2



STEP 3




STEP 4
COMPLETE



PAGE 3 OF 3





Note: Dimension tolerance ±5%