

#### 1828-SECTPH

# FLEXSTEEL°

© Flexsteel Industries, Inc. | Last Updated 02/22

Jarvis | 1828

LEATHER

# Jarvis | 1828

23	SPH SPH PPH	FEATURES	PRODUCT DIMENSIONS	OVERALL			SEAT					
65				Height	Width	Depth	Height	Width	Depth	Arm Height	Open Depth	Wall Clearance
		Flexsteel Spring Unit DualFlex	Full Wedge -23	41″	66″	47″	20″	41″	22″	20″		
	•	Attochod	RAF Power Reclining Loveseat with Power Headrest -66PH	41″	55″	40″	20″	46″	22″	25″	65″	6″
		Seat Construction Attached Seat Cushion(s) High-Density (HC)	LAF Power Reclining Loveseat with Power Headrest -65PH	41″	55″	40″	20″	46″	21″	25″	65″	6″
			Armless Power Recliner with Power Headrest -59PH	41″	24″	40″	20″	24″	22″	25″	65″	6″
			Armless Chair -19	41″	24″	40″	20″	24″	22″	20″		

• Standard o Optional

### F L E X S T E E L°

### Jarvis | 1828

#### Stocked Colors

Parchment <b>009-12</b> Leather/Vinyl	Mica <b>009-70</b> Leather/Vinyl	

Printed samples may vary from actual swatches. Please refer to swatches for actual color.

#### NOTES

Contemporary look with clean lines, sleek  $\operatorname{arms}$  and intricate cross-stitching

Built to last with our DualFlex Spring System—sturdy steel ribbons attached to flexible coils that offer a wide range of motion and durability

Power controls on either side independently adjust the headrest and recline for a personalized sit

Separate home buttons on either side return the headrest and footrest to their original positions with one touch

Attached seat and back cushions stay neatly in place and ensure a lasting, comfortable sit

High-density cushions consist of a high-resiliency, high-density polyurethane foam core

Durable leather upholstery holds up in the most demanding environments

USB port built into power control for convenient charging

The power control allows you to independently adjust the recline and headrest.

A separate home button returns the headrest and footrest to their original positions with one touch.

A USB port is included on the power control for powering electronics.

Zero draw technology only uses power when the USB port is in use.



Power Recline & Headrest

FLEXSTEEL




### Latitudes Collection | Reclining Sectionals


## Jarvis Power Sectional 1828 leather

### **Components & Configurations**

#### Components

LAF = Left-Arm-Facing RAF = Right-Arm-Facing






-47"—

Full Wedge




⊢ 24" –


Armless Power Recliner with Power Headrest




1828-65PH LAF Power Reclining Loveseat with Power Headrest



### Sample Configurations





Scale 1/4"=1' Dimensions are in inches and are subject to variance. Options are subject to change without notice.

© Flexsteel Industries, Inc. 11/20 FLX-CP-LR-CC-1828