

CLA-022-203 D'ORSAY

CARACOLE CLASSIC

ASSEMBLY INSTRUCTIONS


TWO (2) PEOPLE AND PHILIP WRENCH REQUIRED

UNPACK ALL PARTS AND CHECK AGAINST PARTS LIST ON THIS INSTRUCTION SHEET BEFORE DISCARDING
PACKING AND CARTONING!!

- 1) Put the 2 pedestals on a smooth, clean surface then attached the metal base to the pedestal using flat washer (G), lock washer (F) and bolt (E), tighten with wrench provided (H) as shown in Drawing A.
- 2) Turn the Top / Apron Assembly (1) face down on a smooth, clean surface.
- 3) Attach the table base assembled to the top panel using bolt (C), lock washer (B), flat washer (A) ,tighten with wrench provide (D) as shown in Drawing B.
- 4) Using TWO (2) people carefully return the table to the upright position. Leaf could be assembled as needed as shown in Drawing C.

*** NOTE KEEP THIS SHEET!!! ***

In the unlikely event that you would need a replacement part for your furniture, please contact your local authorized Caracole International dealer. If you need replacement hardware quickly, it could be purchased from your local hardware store.




CLA-022-203T		
D'ORSAY TOP		
Part Description	Part No.	QTY
Top/Apron Assembly(1)	CLA-022-203T-40123	1
Dining Table Leaf (2)	CLA-022-203T-4060	2
Dining Table Lock	DINLOCK-001	6sets
RTA Hardware	CLA-022-203T-4001	1

CLA-022-203B		
D'ORSAY BASE		


Part List			
NO.	Hardware List	Part Number	QTY
1		Veneer Top	CLA-022-203T-055
2		The Pedestal	CLA-022-203B-0220
3		The Base	CLA-022-203B-0153
4		Adjustable Floor Glide	CLA-022-203B-075

RTA Hardware for CLA-022-203T				
NO.	Hardware List			Q'ty
A		Flat Washer	5/16"	8
B		Lock Washer	5/16"	8
C		Bolt	5/16"X ⁷ ₈ "	8
D		Wrench	5/16"	1


RTA Hardware for CLA-022-203B			
		Hardware List	QTY
E		Screw (5/16*2-3/4" L)	8
F		Flat Washer	8
G		Spring Washer	8
H		Wrench	1



Drawing A



Drawing B



Drawing C