
COASTER®
FINE FURNITURE

ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

723681
TV CONSOLE

ITEM:**723681**


ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.













WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME | 50 MINUTES | MAX TV SIZE : 64"

PARTS IDENTIFICATION

A	LEFT SIDE PANEL		1 PC	G	TOP PANEL		1 PC
B	RIGHT SIDE PANEL		1 PC	H	CROSS BRACE		1 PC
C	LEFT DIVIDER PANEL		1 PC	I	MIDDLE BACK PANEL		1 PC
D	RIGHT DIVIDER PANEL		1 PC	J	SMALL BACK PANEL		2 PCS
E	BOTTOM PANEL		1 PC	K	LARGE BACK PANEL		2 PCS
F	ADJUSTABLE SHELF		1 PC	L	DOOR		2 PCS

NOTE:





Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.





ITEM:**723681**

COASTER FINE FURNITURE

HARDWARE IDENTIFICATION

Z

NO	DESCRIPTION	FIGURE	Q'TY
1	GLUE 40g		1 PC
2	WOODEN DOWEL Ø8x30mm		36 PCS
3	CAM BOLT Ø7x35.5mm SR		9 PCS
4	CAM LOCK Ø15x12mm SR		9 PCS
5	BOLT Ø9.5x55mm SR		6 PCS
6	PIN Ø4.9x8mm SR		4 PCS
7	PLASTIC FEET Ø15mm		3 PCS

NO	DESCRIPTION	FIGURE	Q'TY
8	SQUARE FOOT		2 PCS
9	HINGE Ø35mm SR		4 PCS
10	HINGE SCREW Ø4x15mm SR		16 PCS
11	HANDLE BLK		2 PCS
12	HANDLE BOLT M5x25mm BLK		4 PCS
13	NUT M5		4 PCS
14	STICKER Ø20mm		2 PCS


Z8,Z9,Z11,Z12,Z13 not included in blister packaging.

NOTE:
Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.


ITEM:**723681**

COASTER FINE FURNITURE

STEP 1




STEP 2



ITEM:**723681**


COASTER FINE FURNITURE

STEP 3



Apply glue on all wooden dowels to ensure integrity of the structure.


STEP 4




ITEM:**723681**

COASTER FINE FURNITURE


STEP 5






Apply glue on all wooden dowels to ensure integrity of the structure.

STEP 6







ITEM:**723681**


COASTER FINE FURNITURE

STEP 7






STEP 8




Apply glue on all wooden dowels to ensure integrity of the structure.


STEP 9




Apply glue on all wooden dowels to ensure integrity of the structure.

STEP 10









ITEM:**723681**


COASTER FINE FURNITURE


STEP 11






STEP 12










ITEM:**723681**

STEP 13










STEP 14

COMPLETE





ITEM:**723681**



Note : Dimension tolerance ±5%