

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life



REVISION 0 : 06/21/2024 REVISION 1 : 02/22/2025

PAGE 1 OF 6

COASTERFURNITURE.COM

ITEM: 115531(B1&B2)



ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.

ASSEMBLY INSTRUCTIONS

- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediatelly.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME
ASSEMIDET TIME



PART IDENTIFICATION

B1 (BOX 1)

- AN TOP
- CN TRESTLE BAR
- DN LEAF

B2 (BOX 2)

BN BASE



2PCS

2PCS

INF FURNITUR

HARDWARE IDENTIFICATION

Z-B1 (BOX 1) - HARDWARE PACK IS LOCATED IN 115531 (B1)

1	THREADED BOLT (5/16" x 100mm - WHT)		2PCS
2	HALF ROUND NUT (22 x 17 x 10mm - WHT)	$\boxed{\bigcirc}$	2PCS
3	HEX NUT (5/16" x 12 - BLK)	9	2PCS
4	HEX BOLT (5/16" x 50mm - BLK)		8PCS
5	LOCK WASHER (1.6 x 14mm - BLK)	Ø	8PCS
6	FLAT WASHER (1 x 18mm - BLK)	\bigcirc	8PCS
7	WRENCH (M12 - RBW)		1PC
8	WOOD DOWEL (10 x 40mm - BRW)		4PCS


NOTE:


Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.


ITEM: 115531(B1&B2) ASSEMBLY INSTRUCTIONS





<u>STEP 1</u>













ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

115531(B1&B2) Dining Table



ITEM: 115531(B1&B2)



ASSEMBLY INSTRUCTIONS


ASSEMBLY TIPS:


- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instruction in the same sequence as numbered to assure fast and easy assembly. **WARNING !**




1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.


2. This product is for home use only and not intended for commercial establishment.









ITEM: 115531(B1&B2) COASTER ASSEMBLY INSTRUCTIONS FINE FURNITURE STEP 5 Ø 0 D 0 മ് **STEP 6**



ITEM: 115531(B1&B2) ASSEMBLY INSTRUCTIONS STEP 9 COMPLETE









ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life



REVISION 0 : 06/21/2024



COASTERFURNITURE.COM

ITEM: 115562 ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:


- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instruction in the same sequence as numbered to assure fast and easy assembly.



WARNING !

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.

2. This product is for home use only and not intended for commercial establishment.




PAGE 2 OF 4


ITEM: 115562 ASSEMBLY INSTRUCTIONS



STEP 1




STEP 2




ITEM: 115562 ASSEMBLY INSTRUCTIONS STEP 3 COMPLETE





ITEM: **115562** COAS ΓER FINE FURNITURE – 24.00" – — 26.00"—— 22.75" 40.00" 1000000 18.00 " 23.00" . 19.50 6 00"



20.75"

COASTERFURNITURE.COM

19.50"

13.50"

¥....¥.