

# ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

509653 *Chair* 

REVISION 0: 10/24/2023

COASTERFURNITURE.COM

#### **ASSEMBLY INSTRUCTIONS**



#### **ASSEMBLY TIPS:**

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



#### **WARNING!**

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

10 MINUTES

#### **PARTS IDENTIFICATION**

A FRONT PANEL	1PC	E SEAT CUSHION	1PC
B SEAT DECK	1PC	F LEFT ARM	1PC
C BACKREST	1PC	G RIGHT ARM	1PC
D BACK CUSHION	1PC	H LEG	4PCS

#### HARDWARE IDENTIFICATION

1 BOLT (5/16" x 25mm - BLK)



4PCS

2 ALLEN WRENCH (60mmx4mm - BLK)




1PC


### COASTER

### ASSEMBLY INSTRUCTIONS

#### STEP 1




#### STEP 2




## COASTER

## ASSEMBLY INSTRUCTIONS STEP 3




#### STEP 4





## COASTER

## ASSEMBLY INSTRUCTIONS STEP 5




#### STEP 6








## ASSEMBLY INSTRUCTIONS STEP 7




## STEP 8 COMPLETE









Note: Dimension tolerance ±5%